

V7E+/LX7-NIO7

V7E+/LX7 Option Switch Settings: 1(Pulse/ICT104U/MDB/RS232 A0)

Supported bill NIO 10, 20, 50, 100, 200, 500, 1000 7 bills.

V7E/LX7 dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject NIO 10 & 20	ON											
★ Accept NIO 10 & 20	OFF											
★ Reject NIO 50 & 100		ON										
★ Accept NIO 50 & 100		OFF										
★ Reject NIO 200			ON									
★ Accept NIO 200			OFF									
★ Reject NIO 500				ON								
★ Accept NIO 500				OFF								
★ Reject NIO 1000					ON							
★ Accept NIO 1000					OFF							
★ Reserved						ON						
★ Reserved						OFF						
Pulse Mode	Other Mode											
★ Harness Disable	BA stops working when fishing						ON					
★ Harness Enable	Normal						OFF					
★ Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ 1 pulse / NIO 10									OFF	OFF		
★ 5 pulses / NIO 10									ON	OFF		
★ 10 pulses / NIO 10									OFF	ON		
★ 20 pulses / NIO 10									ON	ON		
★ Pulse Speed	50ms LO / 50ms HI									OFF	OFF	
	60ms LO / 300ms HI									ON	OFF	
	30ms LO / 50ms HI									OFF	ON	
	150ms LO / 150ms HI									ON	ON	

★ Manufacture setting

V7E+/LX7-NIO7(Pulse/ICT104U/MDB/RS232 A0)

DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Pulse Normal High	ON			
Pulse Normal Low	OFF			
★ Pulse Mode		ON	OFF	
★ ICT104U Interface		OFF	ON	
MDB Interface		ON	ON	
RS232 A0 Mode		OFF	OFF	
★ Reserved				ON
				OFF

DIP SWITCHES SETTING : 2(ICT104U)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
Pulse Mode	OFF			
★ Pulse Mode		ON	OFF	
★ ICT104U Interface		OFF	ON	
MDB Interface		ON	ON	
RS232 A0 Mode		OFF	OFF	
★ Reserved				ON
				OFF

DIP SWITCHES SETTING : 2(MDB)

Currency Assign Data

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON	OFF	
★ ICT104U Interface		OFF	ON	
MDB Interface		ON	ON	
RS232 A0 Mode		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

Interface Bill value	ICT104U	Pulse	MDB
BV1	NIO 10	NIO 10	NIO 10
BV2	NIO 20	NIO 20	NIO 20
BV3	NIO 50	NIO 50	NIO 50
BV4	NIO 100	NIO 100	NIO 100
BV5	NIO 200	NIO 200	NIO 200
BV6	NIO 500	NIO 500	NIO 500
BV7	NIO 1000	NIO 1000	NIO 1000

DIP SWITCHES SETTING : 2(RS232 A0)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
Pulse Mode	OFF			
★ ICT104U Interface		ON	OFF	
MDB Interface		OFF	ON	
RS232 A0 Mode		ON	ON	
★ Reserved				ON
				OFF

★ Manufacture setting

RS232 A0 INFORMATION

BillType Data	
Code	Denomination
1	NIO 10
2	NIO 20
3	NIO 50
4	NIO 100
5	NIO 200
6	NIO 500
7	NIO 1000
8	Reserved

Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

(Please refer to "SW1" setting.)