

XBA mini-MMK6

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill MMK 100, 200, 500, 1000, 5000, 10000 6bills.

XBA mini dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
	Reject MMK 100 & 200	ON											
★	Accept MMK 100 & 200	OFF											
	Reject MMK 500 & 1000		ON										
★	Accept MMK 500 & 1000		OFF										
	Reject MMK 5000			ON									
★	Accept MMK 5000			OFF									
	Reject MMK 10000				ON								
★	Accept MMK 10000				OFF								
	High Acceptance (Nota.2)				ON								
★	High Security				OFF								
	Disable Bill Reject 4 Times BA Stop By 30 Sec				ON								
★	Enable Bill Reject 4 Times BA Stop By 30 Sec				OFF								
	Stack Banknote when Power-up					ON							
★	Reject Banknote when Power-up					OFF							
	Reserved						ON						
★	Reserved						OFF						
	Inhibit Active High							ON					
★	Inhibit Active Low							OFF					
	Reserved								ON				
★	Reserved								OFF				
★	Interface Timing Conversion	50ms LO / 50ms HI								OFF	OFF		
		60ms LO / 300ms HI								ON	OFF		
		30ms LO / 50ms HI								OFF	ON		
		150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note : (1) Calibration card is needed.

(2) High acceptance mode will increase accepting rate, however, it will reduce the security level of Bill Acceptor.

XBA mini-MMK6(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / MMK 100			OFF	OFF
	2 pulses / MMK 100			OFF	ON
	5 pulses / MMK 100			ON	OFF
	20 pulses / MMK 100			ON	ON

★ Manufacture setting.

Interface Settings: 2(Other)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

	INTERFACE	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT JPSTD converter board	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
★	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	100	100	100	100	100
BV2		200	200	200	200
BV3		500	500	500	500
BV4		1000	1000	1000	1000
BV5		5000	5000	5000	5000
BV6		10000	10000	10000	10000