

## TAO-A.V-PKR6

### TAO-A.V Option Switch Settings: 1(Pulse/ICT104V/ICT104U/MDB)

Supported bill PRs 10, 20, 50, 100, 500, 1000 6bills.

TAO-A.V dip-switch settings and functions:

| FUNCTION                      | SW1                           | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW1 | SW2 | SW3 | SW4 |
|-------------------------------|-------------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| ★ Reject PRs 10 & 20          | ON                            |     |     |     |     |     |     |     |     |     |     |     |
| ★ Accept PRs 10 & 20          | OFF                           |     |     |     |     |     |     |     |     |     |     |     |
| ★ Reject PRs 50               |                               | ON  |     |     |     |     |     |     |     |     |     |     |
| ★ Accept PRs 50               |                               | OFF |     |     |     |     |     |     |     |     |     |     |
| ★ Reject PRs 100              |                               |     | ON  |     |     |     |     |     |     |     |     |     |
| ★ Accept PRs 100              |                               |     | OFF |     |     |     |     |     |     |     |     |     |
| ★ Reject PRs 500              |                               |     |     | ON  |     |     |     |     |     |     |     |     |
| ★ Accept PRs 500              |                               |     |     | OFF |     |     |     |     |     |     |     |     |
| ★ Reject PRs 1000             |                               |     |     |     | ON  |     |     |     |     |     |     |     |
| ★ Accept PRs 1000             |                               |     |     |     | OFF |     |     |     |     |     |     |     |
| ★ Reserved                    |                               |     |     |     |     | ON  |     |     |     |     |     |     |
| ★ Reserved                    |                               |     |     |     |     | OFF |     |     |     |     |     |     |
| <b>Pulse Mode</b>             | <b>Other Mode</b>             |     |     |     |     |     |     |     |     |     |     |     |
| ★ Harness Disable             | BA stops working when fishing |     |     |     |     |     | ON  |     |     |     |     |     |
| ★ Harness Enable              | Normal                        |     |     |     |     |     | OFF |     |     |     |     |     |
| ★ Inhibit Active High         |                               |     |     |     |     |     |     | ON  |     |     |     |     |
| ★ Inhibit Active Low          |                               |     |     |     |     |     |     | OFF |     |     |     |     |
| ★ 1 pulse / PRs10             |                               |     |     |     |     |     |     |     | OFF | OFF |     |     |
| ★ 5 pulses / PRs10            |                               |     |     |     |     |     |     |     | ON  | OFF |     |     |
| ★ 10 pulses / PRs10           |                               |     |     |     |     |     |     |     | OFF | ON  |     |     |
| ★ 20 pulses / PRs10           |                               |     |     |     |     |     |     |     | ON  | ON  |     |     |
| ★ Interface Timing Conversion | 50ms LO / 50ms HI             |     |     |     |     |     |     |     |     |     | OFF | OFF |
|                               | 60ms LO / 300ms HI            |     |     |     |     |     |     |     |     |     | ON  | OFF |
|                               | 30ms LO / 50ms HI             |     |     |     |     |     |     |     |     |     | OFF | ON  |
|                               | 150ms LO / 150ms HI           |     |     |     |     |     |     |     |     |     | ON  | ON  |

★ Manufacture setting

◆ Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

(Please refer to "SW1" setting.)

## Appendix

## TAO-A.V-PKR6(Pulse/ICT104V/ICT104U/MDB)

### Interface Settings: 3(Pulse)

| INTERFACE                  | SW1 | SW2 | SW3 | SW4 |
|----------------------------|-----|-----|-----|-----|
| ★ Credit-Pulse Normal HIGH | ON  |     |     |     |
| Credit-Pulse Normal LOW    | OFF |     |     |     |
| ★ Pulse Mode               |     | ON  | OFF |     |
| MDB Interface              |     | ON  | ON  |     |
| ICT104V Interface          |     | OFF | ON  |     |
| ICT104U Interface          |     | OFF | OFF |     |
| ★ Reserved                 |     |     |     | ON  |
|                            |     |     |     | OFF |

★ Manufacture setting

### Interface Settings: 3(ICT104V)

| INTERFACE           | SW1 | SW2 | SW3 | SW4 |
|---------------------|-----|-----|-----|-----|
| ★ Reserved          | ON  |     |     |     |
| Reserved            | OFF |     |     |     |
| Pulse Mode          |     | ON  | OFF |     |
| MDB Interface       |     | ON  | ON  |     |
| ★ ICT104V Interface |     | OFF | ON  |     |
| ICT104U Interface   |     | OFF | OFF |     |
| ★ Reserved          |     |     |     | ON  |
|                     |     |     |     | OFF |

★ Manufacture setting

### Currency Assign Data

| Interface<br>Bill value | ICT104U  | Pulse    | MDB      | ICT104V  |
|-------------------------|----------|----------|----------|----------|
| BV1                     | PRs 10   | PRs 10   | PRs 10   | PRs 10   |
| BV2                     | PRs 20   | PRs 20   | PRs 20   | PRs 20   |
| BV3                     | PRs 50   | PRs 50   | PRs 50   | PRs 50   |
| BV4                     | PRs 100  | PRs 100  | PRs 100  | PRs 100  |
| BV5                     | PRs 500  | PRs 500  | PRs 500  | PRs 500  |
| BV6                     | PRs 1000 | PRs 1000 | PRs 1000 | PRs 1000 |

### Interface Settings: 3(ICT104U)

| INTERFACE           | SW1 | SW2 | SW3 | SW4 |
|---------------------|-----|-----|-----|-----|
| ★ Reserved          | ON  |     |     |     |
| Reserved            | OFF |     |     |     |
| Pulse Mode          |     | ON  | OFF |     |
| MDB Interface       |     | ON  | ON  |     |
| ★ ICT104V Interface |     | OFF | ON  |     |
| ★ ICT104U Interface |     | OFF | OFF |     |
| ★ Reserved          |     |     |     | ON  |
|                     |     |     |     | OFF |

★ Manufacture setting

### Interface Settings: 3(MDB)

| FUNCTION  | SW1 | SW2 | SW3 | SW4 |
|---|-----|-----|-----|-----|
| ★ Scaling Factor (SF) = 100<br>Decimal Point Position (DPP) = 2 | ON  |     |     |     |
| Scaling Factor (SF) = 1<br>Decimal Point Position (DPP) = 0     | OFF |     |     |     |
| Pulse Mode  |     | ON  | OFF |     |
| ★ MDB Interface   |     | ON  | ON  |     |
| ICT104V Interface   |     | OFF | ON  |     |
| ICT104U Interface   |     | OFF | OFF |     |
| ★ Reserved  |     |     |     | ON  |
|   |     |     |     | OFF |

★ Manufacture setting