

BR2300-IDR7

BR2300 DIP SWITCHES SETTING : (MDB/ICT-BC)

Supported bill IDR 1000, 2000, 5000, 10000, 20000 50000, 100000 7 bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	Reject IDR 1000 & 2000 & 5000	ON									
★	Accept IDR 1000 & 2000 & 5000	OFF									
	Reject IDR 10000 & 20000		ON								
★	Accept IDR 10000 & 20000		OFF								
	Reject IDR 50000 & 100000			ON							
★	Accept IDR 50000 & 100000			OFF							
	High Acceptance (Note.3)				ON						
★	High Security				OFF						
	MDB Display Setting(See Table 1)(MDB Only)					ON					
★	MDB Display Setting(See Table 1)(MDB Only)					OFF					
★	Normal						OFF	OFF			
	Load Banknote to Recycle						ON	OFF			
	Load Banknote to Stacker						OFF	ON			
	Unload Banknote to Stacker						ON	ON			
	MDB Display Setting(See Table 1)(MDB Only)								ON		
★	MDB Display Setting(See Table 1)(MDB Only)								OFF		
★	ICT-BC Mode									ON	
★	MDB Mode									OFF	
	MDB Mode	ICT-BC Mode									
	Virtual MDB Recycler Function (Note.1)	Connect with MDB Connector									ON
★	Standard MDB Recycler Function	Connect with RS232 Connector									OFF

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note.1: Recycled Banknote represents virtual MDB coin type.

Note.2: calibrate card.

Note.3: High acceptance mode will increasing accepting rate, however, it will reduce the security level of Bill Acceptor.

Note.4: Normal: Scaling Factor (SF) = 1
Decimal Point Position (DPP) = 0

Note.5: The function(credit divide by 1000) is only used at standard MDB recycler mode

Note.6: The function(credit divide by 100) is only used at standard MDB recycler mode

BR2300 - IDR7 (MDB/ICT-BC)

Currency Assign Data

Interface Bill value	ICT-BC	MDB		
		Note.4	Note.5	Note.6
BV1	IDR 1000	IDR 1000	IDR 1	IDR 10
BV2	IDR 2000	IDR 2000	IDR 2	IDR 20
BV3	IDR 5000	IDR 5000	IDR 5	IDR 50
BV4	IDR 10000	IDR 10000	IDR 10	IDR 100
BV5	IDR 20000	IDR 20000	IDR 20	IDR 200
BV6	IDR 50000	IDR 50000	IDR 50	IDR 500
BV7	IDR 100000	IDR 100000	IDR 100	IDR 1000

Note.4: Normal: Scaling Factor (SF) = 1

Decimal Point Position (DPP) = 0

Note.5: The function(credit divide by 1000) is only used at standard MDB recycler mode

Note.6: The function(credit divide by 100) is only used at standard MDB recycler mode

Table 1

	Sw5	Sw8
★ Normal Credit (Note.4)	OFF	OFF
Credit divide by 1000 (Note.5)	OFF	ON
Credit divide by 100 (Note.6)	ON	OFF
Reserved	ON	ON