

BR2300-VND9

BR2300 DIP SWITCHES SETTING : (MDB/ICT-BC/MDB Dummy)

Supported bill VND 1000, 2000, 5000, 10000, 20000
50000, 100000, 200000, 500000 9 bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	Reject VND 1000 & 2000 (Note.2)	ON									
★	Accept VND 1000 & 2000 (Note.2)	OFF									
★	Reject VND 5000 & 10000 & 20000 & 50000		ON								
★	Accept VND 5000 & 10000 & 20000 & 50000		OFF								
★	Reject VND 100000 & 200000 & 500000			ON							
★	Accept VND 100000 & 200000 & 500000			OFF							
★	Normal Credit (Note.5)				OFF	OFF					
	Credit divide by 1000 (Note.6)				OFF	ON					
	Credit divide by 100 (Note.7)				ON	OFF					
	Reserved				ON	ON					
★	Normal						OFF	OFF			
	Load Banknote to Recycle						ON	OFF			
	Load Banknote to Stacker						OFF	ON			
	Unload Banknote to Stacker						ON	ON			
★	MDB Mode								OFF	OFF	
★	MDB Dummy Mode								ON	OFF	
★	ICT-BC Mode								OFF	ON	
	Reserved								ON	ON	
	MDB Mode	ICT-BC Mode		MDB Dummy Mode							
	Virtual MDB Recycler Function (Note.1)	Connect with MDB Connector		No Refund After the Deal							ON
★	Standard MDB Recycler Function	★ Connect with RS232 Connector		★ Refund After the Deal							OFF

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note.1: Recycled Banknote represents virtual MDB coin type.

Note.2:** MDB (Dummy) Mode:

When Dip 1 is OFF, Reject VND 500000.

When Dip 1 is ON, Accept VND 500000.

Note.3: calibrate card.

Note.4: High acceptance mode will increase accepting rate, however, it will reduce the security level of Bill Acceptor.

Note.5: Normal: Scaling Factor (SF) = 1

Decimal Point Position (DPP) = 0

Note.6: The function(credit divide by 1000) is only used at standard MDB recycler mode

Note.7: The function(credit divide by 100) is only used at standard MDB recycler mode

BR2300 - VND9 (MDB/ICT-BC/MDB Dummy)

Currency Assign Data

Interface	ICT-BC	MDB (Dummy)					
		When Dip 1 is OFF			When Dip 1 is ON		
		Note.5	Note.6	Note.7	Note.5	Note.6	Note.7
BV1	VND 1000	VND 1000	VND 1	VND 10	VND 5000	VND 5	VND 50
BV2	VND 2000	VND 2000	VND 2	VND 20	VND 10000	VND 10	VND 100
BV3	VND 5000	VND 5000	VND 5	VND 50	VND 20000	VND 20	VND 200
BV4	VND 10000	VND 10000	VND 10	VND 100	VND 50000	VND 50	VND 500
BV5	VND 20000	VND 20000	VND 20	VND 200	VND 100000	VND 100	VND 1000
BV6	VND 50000	VND 50000	VND 50	VND 500	VND 200000	VND 200	VND 2000
BV7	VND 100000	VND 100000	VND 100	VND 1000	VND 500000	VND 500	VND 5000
BV8	VND 200000	VND 200000	VND 200	VND 2000			
BV9	VND 500000						

Note.5: Normal: Scaling Factor (SF) = 1

Decimal Point Position (DPP) = 0

Note.6: The function(credit divide by 1000) is only used at standard MDB recycler mode

Note.7: The function(credit divide by 100) is only used at standard MDB recycler mode

Recycler banknote inventory	
VND 1000	45 pcs
VND 2000	45 pcs
VND 5000	45 pcs
VND 10000	45 pcs
VND 20000	45 pcs
VND 50000	40 pcs
VND 100000	40 pcs
VND 200000	40 pcs
VND 500000	40 pcs