BRV-IDR7

BRV Option Switch Settings: 1(ICT-BC/MDB/VCCS Dummy/MDB Dummy)

Supported bill IDR 1000, 2000, 5000, 10000, 20000. 50000, 100000   7bills.

BRV dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
Reject IDR 1000 & 2000 & 5000 & 10000	ON											
★ Accept IDR 1000 & 2000 & 5000 & 10000	OFF											
Reject IDR 20000		ON										
★ Accept IDR 20000		OFF										
Reject IDR 50000			ON									
★ Accept IDR 50000			OFF									
Reject IDR 100000				ON								
★ Accept IDR 100000				OFF								
★ Reserved					ON							
★ Reserved					OFF							
★ Normal							OFF	OFF				
Load Banknote to Recycle							ON	OFF				
Load Banknote to Stacker							OFF	ON				
Unload Banknote to Stacker							ON	ON				
High Acceptance (Note.4)								ON				
★ High Security								OFF				

MDB Mode	MDB Dummy Mode	SW1	SW2	SW3	SW4	VCCS Dummy Mode	SW1	SW2	SW3	SW4
Reserved	Reserved	ON				★ 255 Bank Note Limitation Per Transaction	ON	ON	ON	
★ Reserved	Reserved	OFF				1 Bank Note Limitation Per Transaction	OFF	OFF	OFF	
Reserved	Reserved		ON			2 Bank Note Limitation Per Transaction	ON	OFF	OFF	
Reserved	Reserved		OFF			3 Bank Note Limitation Per Transaction	OFF	ON	OFF	
Reserved	Reserved			ON		4 Bank Note Limitation Per Transaction	ON	ON	OFF	
★ Reserved	Reserved			OFF		5 Bank Note Limitation Per Transaction	OFF	OFF	ON	
						6 Bank Note Limitation Per Transaction	ON	OFF	ON	
						7 Bank Note Limitation Per Transaction	OFF	ON	ON	
Virtual MDB (Note.5) Recycler Function	No Refund After the Deal				ON	No Refund After the Deal				ON
★ Standard MDB Recycler Function	★ Refund After the Deal				OFF	★ Refund After the Deal				OFF

★ Manufacture setting

Note：
(1) After setting dip switch of the credit pulses,you should reset the bill acceptor again.
(2) Please reset the bill acceptor after set the dip switch.
(3) Calibration card is needed.
(4) High acceptance mode will increasing accepting rate, however, it will reduce the security level of Bill Acceptor.
(5) Recycked Banknote represents virtual MDB coin type.
(6) Normal:Scaling Factor (SF) = 1
    Decimal Point Position (DPP) = 0
(7) The function(credit divide by1000) is used at standard MDB recycler mode
(8) The function(credit divide by100) is used at standard MDB recycler mode

Appendix

BRV-IDR7(ICT-BC/MDB/VCCS Dummy/MDB Dummy)

Interface Settings: 2(ICT-BC)

INTERFACE	SW5	SW6	SW7	SW8
Reserved	ON			
★ Reserved	OFF			
Connect with MDB Connector		ON		
★ Connect with RS232 Connector		OFF		
MDB Mode			OFF	OFF
VCCS Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
★ ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(VCCS Dummy)

INTERFACE	SW5	SW6	SW7	SW8
Escrow (VCCS Dummy Mode)	ON			
★ No Escrow (VCCS Dummy Mode)	OFF			
Reserved		ON		
★ Reserved		OFF		
MDB Mode			OFF	OFF
★ VCCS Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

INTERFACE	SW5	SW6	SW7	SW8
★ Normal Credit (Note.6)	OFF	OFF		
Credit divide by 1000 (Note.7)	OFF	ON		
Credit divide by 100 (Note.8)	ON	OFF		
Reserved	ON	ON		
★ MDB Mode			OFF	OFF
VCCS Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB Dummy)

INTERFACE	SW5	SW6	SW7	SW8
★ Normal Credit (Note.6)	OFF	OFF		
Credit divide by 1000 (Note.7)	OFF	ON		
Credit divide by 100 (Note.8)	ON	OFF		
Reserved	ON	ON		
MDB Mode			OFF	OFF
VCCS Dummy Mode			OFF	ON
★ MDB Dummy Mode			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Bill value \ Interface	VCCS Dummy	ICT-BC	MDB (Dummy) Note.6	MDB (Dummy) Note.7	MDB (Dummy) Note.8	Recycler banknote inventory
BV1	IDR 1000	IDR 1000	IDR 1000	IDR 1	IDR 10	IDR 1000	35 pcs
BV2	IDR 2000	IDR 2000	IDR 2000	IDR 2	IDR 20	IDR 2000	35 pcs
BV3	IDR 5000	IDR 5000	IDR 5000	IDR 5	IDR 50	IDR 5000	35 pcs
BV4	IDR 10000	IDR 10000	IDR 10000	IDR 10	IDR 100	IDR 10000	35 pcs
BV5	IDR 20000	IDR 20000	IDR 20000	IDR 20	IDR 200	IDR 20000	35 pcs
BV6	IDR 50000	IDR 50000	IDR 50000	IDR 50	IDR 500	IDR 50000	30 pcs
BV7	IDR100000	IDR100000	IDR100000	IDR100	IDR1000	IDR100000	30 pcs