



EUR4

L77-P3/P6 DIP SWITCHES SETTING : 1(Pulse/ MDB)

Supported bill Euro 5, 10, 20, 50

4 bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10	
★	1 Pulse / Euro 5	OFF	OFF	OFF								
	2 Pulse / Euro 5	OFF	OFF	ON								
	3 Pulse / Euro 5	OFF	ON	OFF								
	4 Pulse / Euro 5	OFF	ON	ON								
	5 Pulse / Euro 5	ON	OFF	OFF								
	10 Pulse / Euro 5	ON	OFF	ON								
	20 Pulse / Euro 5	ON	ON	OFF								
	100 Pulse / Euro 5	ON	ON	ON								
	Fast output Pulse Lo= 50ms Hi=100ms				ON							
★	Slow output Pulse Lo= 50ms Hi=300ms				OFF							
	Inhibit level Active Low				ON							
	Inhibit level Active High				OFF							
★	Accept Euro 5						ON					
	Reject Euro 5						OFF					
★	Accept Euro 10							ON				
	Reject Euro 10							OFF				
★	Accept Euro 20								ON			
	Reject Euro 20								OFF			
★	Accept Euro 50									ON		
	Reject Euro 50									OFF		
	Reserved										ON	
★	Reserved										OFF	

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

L77-EUR4P3/P6(Pulse/MDB)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Mode		ON		
	MDB Interface		OFF		
★	Reserved			ON	
				OFF	
★					ON
★					OFF

★ Manufacture setting

DIP SWITCHES SETTING : 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	MDB Interface		OFF		
★	Reserved			ON	
				OFF	
★					ON
★					OFF

★ Manufacture setting