

GBP2+SCO2+EUR3

L77.L77F-P3/P6 DIP SWITCHES SETTING : 1(Pulse/MDB)

Supported bill

English banknotes: England £ 5, £ 10

Scottish banknotes:

Royal Bank & Bank of Scotland & Clydesdale Bank £ 5, £ 10

EUR banknotes: €5, €10, €20

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10	
★	1 Pulse / € 0.5	OFF	OFF	OFF								
	2 Pulse / € 0.5	OFF	OFF	ON								
	3 Pulse / € 0.5	OFF	ON	OFF								
	4 Pulse / € 0.5	OFF	ON	ON								
	5 Pulse / € 0.5	ON	OFF	OFF								
	10 Pulse / € 0.5	ON	OFF	ON								
	20 Pulse / € 0.5	ON	ON	OFF								
	100 Pulse / € 0.5	ON	ON	ON								
★	Fast output Pulse Lo= 50ms Hi=100ms				ON							
	Slow output Pulse Lo= 50ms Hi=300ms				OFF							
★	Inhibit level Active Low					ON						
	Inhibit level Active High					OFF						
★	Accept £ 5						ON					
	Reject £ 5						OFF					
★	Accept £ 10							ON				
	Reject £ 10							OFF				
★	Accept € 5								ON			
	Reject € 5								OFF			
★	Accept € 10									ON		
	Reject € 10									OFF		
★	Accept € 20										ON	
	Reject € 20										OFF	

★ Manufacture setting

Note:(1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

(3) £ 1.00=€ 1.50

L77.L77F-GEP7(Pulse/MDB)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Mode		ON		
	MDB Mode		OFF		
★	Reserved			ON	
				OFF	
★					ON
★					OFF

★ Manufacture setting

DIP SWITCHES SETTING : 3(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	MDB Interface		OFF		
★	Reserved			ON	
				OFF	
★					ON
★					OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	Pulse	MDB
BV1	£ 5	£ 5
BV2	£ 10	£ 10
BV3	€ 5	€ 5
BV4	€ 10	€ 10
BV5	€ 20	€ 20