

L77F/PL77-KGS7

L77F/PL77 Option Switch Settings : 1(Pulse/MDB/ccNet)

Supported bill KGS 20, 50, 100, 200, 500, 1000, 5000 7bills.

L77F/PL77 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / KGS 10	OFF	OFF	OFF							
	2 Pulse / KGS 10	OFF	OFF	ON							
	3 Pulse / KGS 10	OFF	ON	OFF							
	4 Pulse / KGS 10	OFF	ON	ON							
	5 Pulse / KGS 10	ON	OFF	OFF							
	10 Pulse / KGS 10	ON	OFF	ON							
	20 Pulse / KGS 10	ON	ON	OFF							
	100 Pulse / KGS 10	ON	ON	ON							
	Fast output Pulse Lo= 50ms Hi=100ms				ON						
★	Slow output Pulse Lo= 50ms Hi=300ms				OFF						
	Inhibit level Active Low				ON						
★	Inhibit level Active High				OFF						
★	Accept KGS 20 & 50				ON						
	Reject KGS 20 & 50				OFF						
★	Accept KGS 100 & 200				ON						
	Reject KGS 100 & 200				OFF						
★	Accept KGS 500 & 1000				ON						
	Reject KGS 500 & 1000				OFF						
★	Accept KGS 5000				ON						
	Reject KGS 5000				OFF						
	Simulation Bill Box Has Been Removed				ON						
★	Default				OFF						

◆ Manufacture Default setting.

Note : (1) Please reset the bill acceptor after any changes on Dip switch.

(2) Dip Switch 1 to 5 are only for Pulse mode.

(3) MDB Mode:

When Dip 6 is OFF,Accept KGS 5000.

When Dip 6 is ON ,Reject KGS 5000.

L77F/PL77-KGS7(Pulse/MDB/ccNet)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Interface		ON	OFF	
	MDB Interface		ON	ON	
	ccNet Interface		OFF	OFF	
	Reserved		OFF	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

Interface Settings: 2(ccNet)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	Pulse Interface		ON	OFF	
	MDB Interface		ON	ON	
★	ccNet Interface		OFF	OFF	
	Reserved		OFF	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	Pulse	ccNet	MDB	
			When Dip 6 is OFF	When Dip 6 is ON
BV1	KGS 20	KGS 20	KGS 100	KGS 20
BV2	KGS 50	KGS 50	KGS 200	KGS 50
BV3	KGS 100	KGS 100	KGS 500	KGS 100
BV4	KGS 200	KGS 200	KGS 1000	KGS 200
BV5	KGS 500	KGS 500	KGS 5000	KGS 500
BV6	KGS 1000	KGS 1000		KGS 1000
BV7	KGS 5000	KGS 5000		

Interface Settings: 2(MDB)

	INTERFACE	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
★	Pulse Interface		ON	OFF	
	MDB Interface		ON	ON	
	ccNet Interface		OFF	OFF	
	Reserved		OFF	ON	
★	Reserved				ON
					OFF

★ Manufacture setting