



EUR4

L83 DIP SWITCHES SETTING : 1(RS232 A1/PULSE)

Supported bill Euro 5(02), 10(02), 20(02), 50(02) 4bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★ 1 Pulse / Euro 5	OFF	OFF	OFF							
2 Pulse / Euro 5	OFF	OFF	ON							
3 Pulse / Euro 5	OFF	ON	OFF							
4 Pulse / Euro 5	OFF	ON	ON							
5 Pulse / Euro 5	ON	OFF	OFF							
10 Pulse / Euro 5	ON	OFF	ON							
20 Pulse / Euro 5	ON	ON	OFF							
100 Pulse / Euro 5	ON	ON	OFF							
Fast output Pulse	Lo= 50ms Hi=100ms			ON						
★ Slow output Pulse	Lo= 50ms Hi=300ms			OFF						
Inhibit level Active Low					ON					
★ Inhibit level Active High					OFF					
★ Accept Euro 5						ON				
Reject Euro 5						OFF				
★ Accept Euro 10							ON			
Reject Euro 10							OFF			
★ Accept Euro 20								ON		
Reject Euro 20								OFF		
★ Accept Euro 50									ON	
Reject Euro 50									OFF	
HOLD										ON
										OFF

★ Manufacture setting

Note:(1)Please reset the bill acceptor after set the dip switch.

(2)Dip switches 1 to 5 are only used for pulse protocol.

L83-EUR4(RS232 A1/Pulse)

DIP SWITCHES SETTING : 2(Pulse)

FUNCTION	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
RS232 A1 Mode		OFF		
★ Reserved			ON	
			OFF	
				ON
				OFF

★ Manufacture setting

DIP SWITCHES SETTING : 2(RS232 A1)

FUNCTION	SW1	SW2	SW3	SW4
Reserve	ON			
Reserve	OFF			
Pulse Mode		ON		
★ RS232 A1 Mode		OFF		
★ Reserved			ON	
			OFF	
				ON
				OFF

★ Manufacture setting