

## S7ER-TZS5 Option Switch Settings: (Pulse)

Supported bill TZS 500, 1000, 2000, 5000, 10000 5bills.

S7ER dip-switch settings and functions:

|   | FUNCTION   | SW1                 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW1 | SW2 | SW3 | SW4 | SW1 | SW2 | SW3 | SW4 |
|---|--|---------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|   | Reject TZS 500                                   | ON                  |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |
| ★ | Accept TZS 500                                   | OFF                 |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |
|   | Reject TZS 1000                                  |                     | ON  |     |     |     |     |     |     |     |     |     |     |     |     |     |     |
| ★ | Accept TZS 1000                                  |                     | OFF |     |     |     |     |     |     |     |     |     |     |     |     |     |     |
|   | Reject TZS 2000                                  |                     |     | ON  |     |     |     |     |     |     |     |     |     |     |     |     |     |
| ★ | Accept TZS 2000                                  |                     |     | OFF |     |     |     |     |     |     |     |     |     |     |     |     |     |
|   | Reject TZS 5000                                  |                     |     |     | ON  |     |     |     |     |     |     |     |     |     |     |     |     |
| ★ | Accept TZS 5000                                  |                     |     |     | OFF |     |     |     |     |     |     |     |     |     |     |     |     |
|   | Reject TZS 10000                                 |                     |     |     |     | ON  |     |     |     |     |     |     |     |     |     |     |     |
| ★ | Accept TZS 10000                                 |                     |     |     |     | OFF |     |     |     |     |     |     |     |     |     |     |     |
|   | Disable Bill Reject 4 Times<br>BA Stop By 30 Sec |                     |     |     |     | ON  |     |     |     |     |     |     |     |     |     |     |     |
| ★ | Enable Bill Reject 4 Times<br>BA Stop By 30 Sec  |                     |     |     |     | OFF |     |     |     |     |     |     |     |     |     |     |     |
|   | Stack Banknote when Power-up                     |                     |     |     |     |     | ON  |     |     |     |     |     |     |     |     |     |     |
| ★ | Reject Banknote when Power-up                    |                     |     |     |     |     | OFF |     |     |     |     |     |     |     |     |     |     |
|   | Inhibit Active HIGH                              |                     |     |     |     |     |     | ON  |     |     |     |     |     |     |     |     |     |
| ★ | Inhibit Active LOW                               |                     |     |     |     |     |     | OFF |     |     |     |     |     |     |     |     |     |
|   | Pulse Speed                                      | 100ms HI / 100ms LO |     |     |     |     |     | ON  |     |     |     |     |     |     |     |     |     |
| ★ |  | 50ms HI / 50ms LO   |     |     |     |     |     | OFF |     |     |     |     |     |     |     |     |     |
|   | Reserved   |                     |     |     |     |     |     |     | ON  |     |     |     |     |     |     |     |     |
| ★ | Reserved   |                     |     |     |     |     |     |     | OFF |     |     |     |     |     |     |     |     |
|   | Reserved   |                     |     |     |     |     |     |     |     | ON  |     |     |     |     |     |     |     |
| ★ | Reserved   |                     |     |     |     |     |     |     |     | OFF |     |     |     |     |     |     |     |
|   | Reserved   |                     |     |     |     |     |     |     |     |     | ON  |     |     |     |     |     |     |
| ★ | Reserved   |                     |     |     |     |     |     |     |     |     | OFF |     |     |     |     |     |     |
|   | Reserved   |                     |     |     |     |     |     |     |     |     |     | ON  |     |     |     |     |     |
| ★ | Reserved   |                     |     |     |     |     |     |     |     |     |     | OFF |     |     |     |     |     |
|   | Credit-Pulse Normal HIGH                         |                     |     |     |     |     |     |     |     | ON  |     |     |     |     |     |     |     |
| ★ | Credit-Pulse Normal LOW                          |                     |     |     |     |     |     |     |     | OFF |     |     |     |     |     |     |     |
|   | Pulse Mode                                       |                     |     |     |     |     |     |     |     |     | ON  |     |     |     |     |     |     |
| ★ | ICT104U Mode                                     |                     |     |     |     |     |     |     |     | OFF |     |     |     |     |     |     |     |
|   | 1 pulse / TZS 500                                |                     |     |     |     |     |     |     |     |     |     | OFF | OFF |     |     |     |     |
| ★ | 2 pulses / TZS 500                               |                     |     |     |     |     |     |     |     |     |     |     | OFF | ON  |     |     |     |
|   | 4 pulses / TZS 500                               |                     |     |     |     |     |     |     |     |     |     |     |     | ON  | OFF |     |     |
| ★ | 20 pulses / TZS 500                              |                     |     |     |     |     |     |     |     |     |     |     |     |     | ON  | ON  |     |

★ Manufacture setting

Note: 1. After setting dip switch of the credit pulses, you should reset the bill acceptor again.

## S7ER-TZS5 (ICT104U)

S7ER dip-switch settings and functions:

|   | FUNCTION   | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW1 | SW2 | SW3 | SW4 | SW1 | SW2 | SW3 | SW4 |
|---|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|   | Reject TZS 500                                   | ON  |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |
| ★ | Accept TZS 500                                   | OFF |     |     |     |     |     |     |     |     |     |     |     |     |     |     |     |
|   | Reject TZS 1000                                  |     | ON  |     |     |     |     |     |     |     |     |     |     |     |     |     |     |
| ★ | Accept TZS 1000                                  |     | OFF |     |     |     |     |     |     |     |     |     |     |     |     |     |     |
|   | Reject TZS 2000                                  |     |     | ON  |     |     |     |     |     |     |     |     |     |     |     |     |     |
| ★ | Accept TZS 2000                                  |     |     | OFF |     |     |     |     |     |     |     |     |     |     |     |     |     |
|   | Reject TZS 5000                                  |     |     |     | ON  |     |     |     |     |     |     |     |     |     |     |     |     |
| ★ | Accept TZS 5000                                  |     |     |     | OFF |     |     |     |     |     |     |     |     |     |     |     |     |
|   | Reject TZS 10000                                 |     |     |     |     | ON  |     |     |     |     |     |     |     |     |     |     |     |
| ★ | Accept TZS 10000                                 |     |     |     |     | OFF |     |     |     |     |     |     |     |     |     |     |     |
|   | Disable Bill Reject 4 Times<br>BA Stop By 30 Sec |     |     |     |     |     | ON  |     |     |     |     |     |     |     |     |     |     |
| ★ | Enable Bill Reject 4 Times<br>BA Stop By 30 Sec  |     |     |     |     |     | OFF |     |     |     |     |     |     |     |     |     |     |
|   | Stack Banknote when Power-up                     |     |     |     |     |     |     | ON  |     |     |     |     |     |     |     |     |     |
| ★ | Reject Banknote when Power-up                    |     |     |     |     |     |     | OFF |     |     |     |     |     |     |     |     |     |
|   | Test Mode  |     |     |     |     |     |     |     | ON  |     |     |     |     |     |     |     |     |
| ★ | Reserved   |     |     |     |     |     |     |     | OFF |     |     |     |     |     |     |     |     |
|   | Reserved   |     |     |     |     |     |     |     |     | ON  |     |     |     |     |     |     |     |
| ★ | Reserved   |     |     |     |     |     |     |     |     | OFF |     |     |     |     |     |     |     |
|   | Reserved   |     |     |     |     |     |     |     |     |     | ON  |     |     |     |     |     |     |
| ★ | Reserved   |     |     |     |     |     |     |     |     |     | OFF |     |     |     |     |     |     |
|   | Reserved   |     |     |     |     |     |     |     |     |     |     | ON  |     |     |     |     |     |
| ★ | Reserved   |     |     |     |     |     |     |     |     |     |     | OFF |     |     |     |     |     |
|   | Reserved   |     |     |     |     |     |     |     |     |     |     |     | ON  |     |     |     |     |
| ★ | Reserved   |     |     |     |     |     |     |     |     |     |     |     | OFF |     |     |     |     |
|   | Pulse Mode                                       |     |     |     |     |     |     |     |     |     |     |     |     | ON  |     |     |     |
| ★ | ICT104U Mode                                     |     |     |     |     |     |     |     |     |     |     |     |     | OFF |     |     |     |
|   | Reserved   |     |     |     |     |     |     |     |     |     |     |     |     |     | ON  |     |     |
| ★ | Reserved   |     |     |     |     |     |     |     |     |     |     |     |     |     | OFF |     |     |
|   | Reserved   |     |     |     |     |     |     |     |     |     |     |     |     |     |     | ON  |     |
| ★ | Reserved   |     |     |     |     |     |     |     |     |     |     |     |     |     |     | OFF |     |

★ Manufacture setting

Note: 1. After setting dip switch of the credit pulses, you should reset the bill acceptor again.

### Currency Assign Data

| Interface | ICT104U   | Pulse     |
|-----------|-----------|-----------|
| BV1       | TZS 500   | TZS 500   |
| BV2       | TZS 1000  | TZS 1000  |
| BV3       | TZS 2000  | TZS 2000  |
| BV4       | TZS 5000  | TZS 5000  |
| BV5       | TZS 10000 | TZS 10000 |

2018 International Currency Technologies Corporation  
V. 1.0 Part Number : SWP4TZ510-R