

V7P-RSD7

V7P Option Switch Settings: 1(Pulse/ICT104V/ICT104U/MDB)

Supported bill RSD 10, 20, 50, 100, 200, 500, 1000 7bills.

V7P dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject RSD 10 & 20	ON											
★	Accept RSD 10 & 20	OFF											
★	Reject RSD 50 & 100		ON										
★	Accept RSD 50 & 100		OFF										
★	Reject RSD 200			ON									
★	Accept RSD 200			OFF									
★	Reject RSD 500			ON									
★	Accept RSD 500			OFF									
★	Reject RSD 1000				ON								
★	Accept RSD 1000				OFF								
★	Reserved				ON								
★	Reserved				OFF								
★	Harness Disable				ON								
★	Harness Enable				OFF								
★	Inhibit Active High							ON					
★	Inhibit Active Low							OFF					
★	1 pulse / RSD 10								OFF	OFF			
★	5 pulses / RSD 10								ON	OFF			
★	10 pulses / RSD 10								OFF	ON			
★	25 pulses / RSD 10								ON	ON			
★	Interface Timing Conversion	50ms LO / 50ms HI								OFF	OFF		
		60ms LO / 300ms HI								ON	OFF		
		30ms LO / 50ms HI								OFF	ON		
		150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

◆ Note : 1.Default setting.

2.Use 2nd and 3rd dip of the internal dip-switch to change different interface Protocol.

3.Remove the front cover and the dip-switch in on the CPU board.

V7P-RSD7(Pulse/ICT104V/ICT104U/MDB)

Interface Settings: 2(Pulse) Currency Assign Data

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON	OFF	
	ICT104U Mode		OFF	OFF	
	ICT104V Mode		OFF	ON	
	MDB Mode		ON	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

Interface	Pulse	MDB	ICT104V	ICT104U
Bill value				
BV1	RSD 10	RSD 10	RSD 10	RSD 10
BV2	RSD 20	RSD 20	RSD 20	RSD 20
BV3	RSD 50	RSD 50	RSD 50	RSD 50
BV4	RSD 100	RSD 100	RSD 100	RSD 100
BV5	RSD 200	RSD 200	RSD 200	RSD 200
BV6	RSD 500	RSD 500	RSD 500	RSD 500
BV7	RSD 1000	RSD 1000	RSD 1000	RSD 1000

Interface Settings: 2(ICT104U/ICT104V)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON	OFF	
★	ICT104U Mode		OFF	OFF	
	ICT104V Mode		OFF	ON	
	MDB Mode		ON	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON	OFF	
★	ICT104U Mode		OFF	OFF	
	ICT104V Mode		OFF	ON	
	MDB Mode		ON	ON	
★	Reserved				ON
					OFF

★ Manufacture setting

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON	OFF	
	ICT104U Mode		OFF	OFF	
	ICT104V Mode		OFF	ON	
★	MDB Mode		ON	ON	
★	Reserved				ON
					OFF

★ Manufacture setting