

XBA mini-SAR4

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill SAR 1, 5, 10, 50 4bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject SAR 1	ON											
★ Accept SAR 1	OFF											
★ Reject SAR 5		ON										
★ Accept SAR 5		OFF										
★ Reject SAR 10			ON									
★ Accept SAR 10			OFF									
★ Reject SAR 50				ON								
★ Accept SAR 50				OFF								
★ Reserved				ON								
★ Reserved				OFF								
★ Disable Bill Reject 4 Times BA Stop By 30 Sec					ON							
★ Enable Bill Reject 4 Times BA Stop By 30 Sec					OFF							
★ Stack Banknote when Power-up						ON						
★ Reject Banknote when Power-up						OFF						
★ High Acceptance (Note.2)							ON					
★ High Security							OFF					
★ Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ Reserved									ON			
★ Reserved									OFF			
★ Interface Timing Conversion		50ms LO / 50ms HI								OFF	OFF	
		60ms LO / 300ms HI								ON	OFF	
		30ms LO / 50ms HI								OFF	ON	
		150ms LO / 150ms HI								ON	ON	

★ Manufacture setting

Note : 1. Calibration card is needed.

2. High acceptance mode will increasing accepting rate, however, it will reduce the security level of Bill Acceptor.

XBA mini-SAR4(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
★ 1 pulse / SAR 1			OFF	OFF
2 pulses / SAR 1			OFF	ON
4 pulses / SAR 1			ON	OFF
20 pulses / SAR 1			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

INTERFACE	SW1	SW2	SW3	SW4
★ Connect with coin changer	ON			
Connect with ICT JPSTD converter board	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
★ ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(Other)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
★ MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	SAR 1	SAR 1	SAR 1	SAR 1	SAR 1
BV2		SAR 5	SAR 5	SAR 5	SAR 5
BV3		SAR 10	SAR 10	SAR 10	SAR 10
BV4					
BV5		SAR 50	SAR 50	SAR 50	SAR 50