

A7/V7 Option Switch Settings**Supported bill BGL 1(99), 2(99), 5(99), 10(99) 4bills.**

A7/V7 dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4	
Reject BGL 1	ON												
Accept BGL 1	OFF												
Reject BGL 2		ON											
Accept BGL 2		OFF											
Reject BGL 5			ON										
Accept BGL 5			OFF										
Reject BGL 10				ON									
Accept BGL 10				OFF									
Reserved					ON								
Reserved					OFF								
High Acceptance						ON							
High Security						OFF							
Harness disable							ON						
Harness enable							OFF						
Inhibit Active High								ON					
Inhibit Active Low								OFF					
1 pulse / one dollar									OFF	OFF			
2 pulse / one dollar									ON	OFF			
4 pulse / one dollar									OFF	ON			
20 pulse / one dollar									ON	ON			
Pulse Speed	50ms on / 50ms off											OFF	OFF
	60ms on / 300ms off											ON	OFF
	30ms on / 50ms off											OFF	ON
	150ms on / 150ms off											ON	ON

◆ Factory configuration has all switches in the OFF position.

Note : (1) Reset the bill acceptor after setting the dip switch.

(2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

