# RUB5

## L70/P5 DIP SWITCHES SETTING : 1(Pulse/RS232 A0)

### Supported bill   Ruble  10, 50, 100, 500, 1000   5bills.

| FUNCTION | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW9 | SW10 |
|---|---|---|---|---|---|---|---|---|---|---|
| ★ 1 Pulse   / Ruble 10 | OFF | OFF | OFF | | | | | | | |
| 2 Pulses / Ruble 10 | OFF | OFF | ON | | | | | | | |
| 3 Pulses / Ruble 10 | OFF | ON | OFF | | | | | | | |
| 4 Pulses / Ruble 10 | OFF | ON | ON | | | | | | | |
| 5 Pulses / Ruble 10 | ON | OFF | OFF | | | | | | | |
| 10 Pulses / Ruble 10 | ON | OFF | ON | | | | | | | |
| 20 Pulses / Ruble 10 | ON | ON | OFF | | | | | | | |
| 100 Pulses /Ruble 10 | ON | ON | ON | | | | | | | |
| Fast output Pulse  Lo= 50ms Hi=100ms | | | | ON | | | | | | |
| ★ Slow output Pulse  Lo= 50ms Hi=300ms | | | | OFF | | | | | | |
| Inhibit level Active Low | | | | | ON | | | | | |
| ★ Inhibit level Active High | | | | | OFF | | | | | |
| ★ Accept   Ruble    10 | | | | | | ON | | | | |
| Reject   Ruble    10 | | | | | | OFF | | | | |
| ★ Accept   Ruble    50 | | | | | | | ON | | | |
| Reject   Ruble    50 | | | | | | | OFF | | | |
| ★ Accept   Ruble   100 | | | | | | | | ON | | |
| Reject   Ruble   100 | | | | | | | | OFF | | |
| ★ Accept   Ruble   500 | | | | | | | | | ON | |
| Reject   Ruble   500 | | | | | | | | | OFF | |
| ★ Accept   Ruble  1000 | | | | | | | | | | ON |
| Reject   Ruble  1000 | | | | | | | | | | OFF |

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.
　　　 (2) Dip switches 1 to 5 are only used for pulse protocol.

---

## L70-RUB5/P5(Pulse/RS232 A0)

### DIP SWITCHES SETTING : 2(Pulse)

| FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|---|---|---|---|
| ★ Credit-Pulse Normal HIGH | ON | | | |
| Credit-Pulse Normal LOW | OFF | | | |
| ★ Pulse Mode | | ON | | |
| RS232 A0 Protocol Mode | | OFF | | |
| ★ Reserved | | | ON | |
| | | | OFF | |
| ★ Reserved | | | | ON |
| ★ | | | | OFF |

★ Manufacture setting

### DIP SWITCHES SETTING : 2(RS232 A0)

| FUNCTION | SW1 | SW2 | SW3 | SW4 |
|---|---|---|---|---|
| ★ Reserved | ON | | | |
| | OFF | | | |
| ★ Pulse Mode | | ON | | |
| RS232 A0 Protocol Mode | | OFF | | |
| ★ Reserved | | | ON | |
| | | | OFF | |
| ★ Reserved | | | | ON |
| ★ | | | | OFF |

★ Manufacture setting