

V7E/LX7-PLN5

V7E/LX7 Option Switch Settings: 1(Pulse/ICT104U/M.D.B)

Supported bill PLN 10, 20, 50, 100, 200 5bills.

V7E/LX7 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject PLN 10	ON											
	Accept PLN 10	OFF											
	Reject PLN 20		ON										
★	Accept PLN 20		OFF										
	Reject PLN 50			ON									
★	Accept PLN 50			OFF									
	Reject PLN 100				ON								
★	Accept PLN 100				OFF								
	Reject PLN 200					ON							
★	Accept PLN 200					OFF							
	Reserved					ON							
★	Reserved					OFF							
	Pulse Mode	Other Mode											
	Harness Disable	BA stops working when fishing					ON						
★	Harness Enable	Normal					OFF						
	Inhibit Active High							ON					
★	Inhibit Active Low							OFF					
★	1 pulse / PLN 10								OFF	OFF			
	2 pulse / PLN 10								ON	OFF			
	4 pulse / PLN 10								OFF	ON			
	20 pulse / PLN 10								ON	ON			
★	Pulse Speed	50ms LO / 50ms HI									OFF	OFF	
		60ms LO / 300ms HI									ON	OFF	
		30ms LO / 50ms HI									OFF	ON	
		150ms LO / 150ms HI									ON	ON	

★ Manufacture setting

Note : (1) Default setting

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

V7E/LX7-PLN5(Pulse/ICT104U/M.D.B)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
	ICT104U Interface		OFF	ON	
★	Pulse Mode		ON	OFF	
	M.D.B Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

Currency Assign Data

Interface Bill value	Pulse	MDB	ICT104U
BV1	10	10	10
BV2	20	20	20
BV3	50	50	50
BV4	100	100	100
BV5	200	200	200

DIP SWITCHES SETTING : 2(ICT)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
★	ICT104U Interface		OFF	ON	
	Pulse Mode		ON	OFF	
	M.D.B Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

DIP SWITCHES SETTING : 2(M.D.B)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100	ON			
	Decimal Point Position (DPP) = 2				
	Scaling Factor (SF) = 1	OFF			
	Decimal Point Position (DPP) = 0				
	ICT104U Interface		OFF	ON	
	Pulse Mode		ON	OFF	
★	M.D.B Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

Note : (1) Default setting

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.