# P77-EUR4 P77/P5 DIP SWITCHES SETTING: 1(Pulse/Parallel A3)

## **Supported bill € 5, 10, 20, 50**

4 bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
*	1 Pulse / € 5	OFF	OFF	OFF							
	2 Pulses / € 5	OFF	OFF	ON							
	3 Pulses / € 5	OFF	ON	OFF							
	4 Pulses / € 5	OFF	ON	ON							
	5 Pulses / € 5	ON	OFF	OFF							
	10 Pulses / € 5	ON	OFF	ON							
	20 Pulses / € 5	ON	ON	OFF							
	100 Pulses / € 5	ON	ON	ON							
	Slow output Pulse Lo=100ms Hi=100ms				ON						
*	Fast output Pulse Lo= 50ms Hi=100ms				OFF						
	Inhibit level Active Low					ON					
*	Inhibit level Active High					OFF					
*	Accept € 5						ON				
	Reject € 5						OFF				
*	Accept € 10							ON			
	Reject € 10							OFF			
*	Accept € 20								ON		
	Reject € 20								OFF		
*	Accept € 50									ON	
	Reject € 50									OFF	
*	Accept Normal										ON
	Reject € 5 (2002) & 10(2002)										OFF

#### ★ Manufacture setting

Note: Please reset the bill acceptor after set the dip switch.

### P77-EUR4/P5(Pulse/Parallel A3)

## **DIP SWITCHES SETTING: 2(Pulse)**

	FUNCTION	SW1	SW2	SW3	SW4
*	Credit-Pulse Normal HIGH				
	Credit-Pulse Normal LOW	OFF			
*	Pulse Protocol		ON		
	Parallel A3 Protocol		OFF		
	Harness Disable			ON	
*	Harness Enable			OFF	
	Reserved				ON
*	Reserved			OFF	

<sup>★</sup> Manufacture setting

## **DIP SWITCHES SETTING: 2(Parallel A3)**

	FUNCTION	SW1	SW2	SW3	SW4
*	Reserved	ON			
	Reserved	OFF			
	Pulse Protocol		ON		
*	Parallel A3 Protocol		OFF		
	Reserved	Reserved ON			
*	Reserved	OFF			
	Reserved				ON
*	Reserved			OFF	

<sup>★</sup> Manufacture setting

## **Currency Assign Data**

Interface Bill value	Parallel A3	Pulse
BV1	5	5
BV2	10	10
BV3	20	20
BV4	50	50