

V77E-UAH9

V77E Option Switch Settings : 1(Pulse/RS232 A0/ccNet/ICT104U)

Supported bill UAH 1, 2, 5, 10, 20, 50, 100, 200, 500 9bills.

V77E dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject UAH 1 & 2 (Note.4)	ON											
★ Accept UAH 1 & 2 (Note.4)	OFF											
★ Reject UAH 5 & 10		ON										
★ Accept UAH 5 & 10		OFF										
★ Reject UAH 20 & 50			ON									
★ Accept UAH 20 & 50			OFF									
★ Reject UAH 100				ON								
★ Accept UAH 100				OFF								
★ Reject UAH 200					ON							
★ Accept UAH 200					OFF							
★ Reject UAH 500						ON						
★ Accept UAH 500						OFF						
★ Harness Disable							ON					
★ Harness Enable							OFF					
★ Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ 1 pulse / UAH 1 & 5 (Note.4)									OFF	OFF		
5 pulses / UAH 1 & 5 (Note.4)									ON	OFF		
10 pulses / UAH 1 & 5 (Note.4)									OFF	ON		
20 pulses / UAH 1 & 5 (Note.4)									ON	ON		
★ Pulse Speed		50ms LO / 50ms HI									OFF	OFF
		60ms LO / 300ms HI									ON	OFF
		30ms LO / 50ms HI									OFF	ON
		150ms LO / 150ms HI									ON	ON

★ Manufacture setting

◆ Factory configuration has all switches in the OFF position.

Note : (1) Default setting

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

(4) Pulse Mode: When Dip 1 is OFF,One Pulse per UAH 1.

When Dip 1 is ON,One Pulse per UAH 5.

V77E-UAH9(Pulse/RS232 A0/ccNet/ICT104U)

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Interface		ON	OFF	
★ RS232 A0 Interface		OFF	ON	
ccNet Interface		ON	ON	
ICT104U Interface		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

Interface Settings: 2(ccNet)

INTERFACE	SW1	SW2	SW3	SW4
19200 Baud rate	ON			
★ 9600 Baud rate	OFF			
Pulse Interface		ON	OFF	
★ RS232 A0 Interface		OFF	ON	
ccNet Interface		ON	ON	
ICT104U Interface		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

Interface Settings: 2(RS232 A0)

INTERFACE	SW1	SW2	SW3	SW4
Reserved	ON			
★ Reserved	OFF			
Pulse Interface		ON	OFF	
★ RS232 A0 Interface		OFF	ON	
ccNet Interface		ON	ON	
ICT104U Interface		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

RS232 A0 INFORMATION

BillType Data	
Code	Denomination
1	UAH 1
2	UAH 2
3	UAH 5
4	UAH 10
5	UAH 20
6	UAH 50
7	UAH 100
8	UAH 200
9	UAH 500

Interface Settings: 2(ICT104U)

INTERFACE	SW1	SW2	SW3	SW4
Reserved	ON			
★ Reserved	OFF			
Pulse Interface		ON	OFF	
★ RS232 A0 Interface		OFF	ON	
ccNet Interface		ON	ON	
ICT104U Interface		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	ccNet	Pulse		RS232 A0	ICT104U
		When Dip 1 is OFF	When Dip 1 is ON		
BV1	UAH 1	UAH 1	UAH 5	UAH 1	UAH 1
BV2	UAH 2	UAH 2	UAH 10	UAH 2	UAH 2
BV3	UAH 5	UAH 5	UAH 20	UAH 5	UAH 5
BV4	UAH 10	UAH 10	UAH 50	UAH 10	UAH 10
BV5	UAH 20	UAH 20	UAH 100	UAH 20	UAH 20
BV6	UAH 50	UAH 50	UAH 200	UAH 50	UAH 50
BV7	UAH 100	UAH 100	UAH 500	UAH 100	UAH 100
BV8	UAH 200	UAH 200		UAH 200	UAH 200
BV9	UAH 500	UAH 500		UAH 500	UAH 500