

V7E/LX7-GEL6

V7E/LX7 Option Switch Settings: 1(Pulse/ICT104U/M.D.B)

Supported bill GEL 5, 10, 20, 50, 100, 200 6bills.

V7E/LX7 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject GEL 5	ON											
	Accept GEL 5	OFF											
	Reject GEL 10		ON										
★	Accept GEL 10		OFF										
	Reject GEL 20			ON									
★	Accept GEL 20			OFF									
	Reject GEL 50				ON								
★	Accept GEL 50				OFF								
	Reject GEL 100					ON							
★	Accept GEL 100					OFF							
	Reject GEL 200						ON						
★	Accept GEL 200						OFF						
	Pulse Mode	Other Mode											
	Harness Disable	BA stops working when fishing						ON					
★	Harness Enable	Normal						OFF					
	Inhibit Active High							ON					
★	Inhibit Active Low							OFF					
★	1 pulse / GEL 5							OFF	OFF				
	2 pulse / GEL 5							ON	OFF				
	5 pulse / GEL 5							OFF	ON				
	20 pulse / GEL 5							ON	ON				
★	Pulse Speed	50ms LO / 50ms HI								OFF	OFF		
		60ms LO / 300ms HI								ON	OFF		
		30ms LO / 50ms HI								OFF	ON		
		150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

Note : (1) Default setting

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

V7E/LX7-GEL6(Pulse/ICT104U/M.D.B)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
	ICT104U Interface		OFF	ON	
★	Pulse Mode		ON	OFF	
	M.D.B Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

Currency Assign Data

Interface Bill value	Pulse	MDB	ICT104U
BV1	5	5	5
BV2	10	10	10
BV3	20	20	20
BV4	50	50	50
BV5	100	100	100
BV6	200	200	200

DIP SWITCHES SETTING : 2(ICT)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
★	ICT104U Interface		OFF	ON	
	Pulse Mode		ON	OFF	
	M.D.B Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

DIP SWITCHES SETTING : 2(M.D.B)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100	ON			
	Decimal Point Position (DPP) = 2				
	Scaling Factor (SF) = 1	OFF			
	Decimal Point Position (DPP) = 0				
	ICT104U Interface		OFF	ON	
	Pulse Mode		ON	OFF	
★	M.D.B Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

Note : (1) Default setting

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.