

V7E/LX7-HUF6

V7E/LX7 Option Switch Settings: 1(Pulse/ICT104U/M.D.B)

Supported bill Ft 500, 1000, 2000, 5000, 10000, 20000 6bills.

V7E/LX7 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject Ft 500	ON											
	Accept Ft 500	OFF											
	Reject Ft 1000		ON										
★	Accept Ft 1000		OFF										
	Reject Ft 2000			ON									
★	Accept Ft 2000			OFF									
	Reject Ft 5000				ON								
★	Accept Ft 5000				OFF								
	Reject Ft 10000				ON								
★	Accept Ft 10000				OFF								
	Reject Ft 20000				ON								
★	Accept Ft 20000				OFF								
	Pulse Mode	Other Mode											
	Harness Disable	BA stops working when fishing						ON					
★	Harness Enable	Normal						OFF					
	Inhibit Active High							ON					
★	Inhibit Active Low							OFF					
★	1 pulse / Ft 500							OFF	OFF				
	5 pulse / Ft 500							ON	OFF				
	10 pulse / Ft 500							OFF	ON				
	20 pulse / Ft 500							ON	ON				
★	Pulse Speed	50ms LO / 50ms HI								OFF	OFF		
		60ms LO / 300ms HI								ON	OFF		
		30ms LO / 50ms HI								OFF	ON		
		150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

Note : 1.Default setting

2.Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

3.Remove the front cover and the dip-switch in on the CPU board.

V7E/LX7-HUF6(Pulse/ICT104U/M.D.B)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal High	ON			
	Credit-Pulse Normal Low	OFF			
★	Pulse Mode		ON	OFF	
	ICT104U Interface		OFF	ON	
	MDB Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

DIP SWITCHES SETTING : 2(ICT104U)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	Pulse Mode		ON	OFF	
★	ICT104U Interface		OFF	ON	
	MDB Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

Currency Assign Data

Interface Bill value	Pulse	ICT	MDB
BV1	500	500	500
BV2	1000	1000	1000
BV3	2000	2000	2000
BV4	5000	5000	5000
BV5	10000	10000	10000
BV6	20000	20000	20000

DIP SWITCHES SETTING : 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON	OFF	
	ICT Interface		OFF	ON	
★	MDB Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

Note 1: Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

2: Remove the front cover and the dip-switch in on the CPU board.