

NE77-RON4

NE77 DIP SWITCHES SETTING : (Pulse/Parallel A4)

Supported bill RON 1, 5, 10, 50 4bills.

DIP SWITCHES SETTING : (Parallel A4)

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
	With Escow Function	ON									
★	No Escow Function	OFF									
	Reserved		ON								
★	Reserved		OFF								
	Reserved			ON							
★	Reserved			OFF							
★	Enable Output Sensor Detect (★★)				ON						
★	Disable Output Sensor Detect (★★)				OFF						
	Reserved				ON						
★	Reserved				OFF						
★	Optical anti-fishing malfunction, BA will be still in working order (★★★)					ON					
★	BA will stop to work when it acknowledges Optical anti-fishing malfunction (★★★)					OFF					
	Accept RON 1 & 5						OFF	OFF			
	Accept RON 5 & 10 & 50						OFF	ON			
	Accept RON 1 & 5 & 10						ON	OFF			
★	Accept RON 1 & 5 & 10 & 50						ON	ON			
★	Operation Mode									ON	
★	Diagnostic Mode									OFF	
	Pulse Protocol										ON
★	Parallel A4 Protocol										OFF

★ Manufacture setting

★★ ON: Autocheck motor reversal.

OFF: When output or hook is triggered in power on, error message displays three red, until after trouble clearing into autocheck.

★★★ ON: (1) After accepted banknotes through output sensor, if detect output trigger again, display sensor problem.

(2) After accepted banknote didn't leave output sensor, display sensor problem.

OFF: (1) After accepted banknotes through output sensor, if detect output trigger again, display sensor problem.

(2) After accepted banknote didn't leave output sensor, return to the idle.

Note: Please restart the bill acceptor after any changes on dip switch(s) has been made.

NE77- RON4 (Pulse/Paralle A4)

DIP SWITCHES SETTING : (Pulse)

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
	5 Pulses / RON 1	ON									
★	1 Pulse / RON 1	OFF									
★	Lo=150ms / Hi=180ms		OFF	OFF							
	Lo= 50ms / Hi= 50ms		OFF	ON							
	Lo= 80ms / Hi=120ms		ON	OFF							
	Lo= 50ms / Hi=300ms		ON	ON							
★	Enable Output Sensor Detect (★★)				ON						
	Disable Output Sensor Detect (★★)				OFF						
	Inhibit level Active High					ON					
★	Inhibit level Active Low					OFF					
★	Optical anti-fishing malfunction, BA will be still in working order (★★★)						ON				
★	BA will stop to work when it acknowledges Optical anti-fishing malfunction (★★★)						OFF				
	Accept RON 1 & 5							OFF	OFF		
	Accept RON 5 & 10 & 50							OFF	ON		
	Accept RON 1 & 5 & 10							ON	OFF		
★	Accept RON 1 & 5 & 10 & 50							ON	ON		
★	Operation Mode									ON	
★	Diagnostic Mode									OFF	
	Pulse Protocol										ON
	Parallel A4 Protocol										OFF

★ Manufacture setting

★★ ON: Autocheck motor reversal.

OFF: When output or hook is triggered in power on, error message displays three red, until after trouble clearing into autocheck.

★★★ ON: (1) After accepted banknotes through output sensor, if detect output trigger again, display sensor problem.

(2) After accepted banknote didn't leave output sensor, display sensor problem.

OFF: (1) After accepted banknotes through output sensor, if detect output trigger again, display sensor problem.

(2) After accepted banknote didn't leave output sensor, return to the idle.

Note: Please restart the bill acceptor after any changes on dip switch(s) has been made.