

NK77F-THB5

NK77F DIP SWITCHES SETTING : (Pulse/Out of Service/Parallel)

Supported bill THB 20, 50, 100, 500, 1000 5bills.

| | FUNCTION | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW9 | SW10 |
|---|------------------------------|---------------------|-----|-----|-----|-----|-----|-----|-----|-----|------|
| ★ | 1 Pulse / THB 10 | OFF | OFF | | | | | | | | |
| | 2 Pulse / THB 10 | OFF | ON | | | | | | | | |
| | 5 Pulse / THB 10 | ON | OFF | | | | | | | | |
| | 10 Pulse / THB 10 | ON | ON | | | | | | | | |
| ★ | Enable Fish Stop | | | ON | | | | | | | |
| | Disable Fish Stop | | | OFF | | | | | | | |
| ★ | Inhibit level Active Low | | | | ON | | | | | | |
| | Inhibit level Active High | | | | OFF | | | | | | |
| ★ | Accept THB 20 & 50 & 100 | | | | | ON | | | | | |
| | Reject THB 20 & 50 & 100 | | | | | OFF | | | | | |
| ★ | Accept THB 500 & 1000 | | | | | | ON | | | | |
| | Reject THB 500 & 1000 | | | | | | OFF | | | | |
| | Enable Output Sensor Detect | | | | | | | ON | | | |
| ★ | Disable Output Sensor Detect | | | | | | | OFF | | | |
| | Pluse Mode | Paralle Mode | | | | | | | | | |
| ★ | Pluse Normal High | Parallel 50ms | | | | | | | ON | | |
| | Pluse Normal Low | Parallel 100ms | | | | | | | OFF | | |
| ★ | Pulse Mode | | | | | | | | | ON | |
| | Parallel Mode | | | | | | | | | OFF | |
| ★ | Power On Motor Plus | | | | | | | | | | ON |
| | Power On Motor Minus | | | | | | | | | | OFF |

(★) Manufacture setting

Currency Assign Data

| Interface Bill value | Parallel | Pulse |
|-------------------------|----------|----------|
| BV1 | THB 20 | THB 20 |
| BV2 | THB 50 | THB 50 |
| BV3 | THB 100 | THB 100 |
| BV4 | THB 500 | THB 500 |
| BV5 | | THB 1000 |

Note:(1) Please reset the bill acceptor after set the dip switch.

(2) Pulse mode has out of service function.

(3) Out of service: Normal High, Error Low.

(4) Pulse speed is LO=50ms/HI=100ms.