

XBA mini-NUO7(NIO3+USD4)

XBA mini Option Switch Settings: 1(MDB/JPSTD/ICT104V/ICT104U)

Supported bill NIO 100, 500, 1000 3bills.
USD 10, 20, 50, 100 4bills.

XBA mini dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject NIO 100	ON											
	Accept NIO 100	OFF											
★	Reject NIO 500		ON										
	Accept NIO 500		OFF										
★	Reject NIO 1000			ON									
	Accept NIO 1000			OFF									
★	Reject USD 10 & 20				ON								
	Accept USD 10 & 20				OFF								
★	Reject USD 50 & 100					ON							
	Accept USD 50 & 100					OFF							
★	Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
	Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
★	Stack Banknote when Power-up							ON					
	Reject Banknote when Power-up							OFF					
★	Reserved								ON				
	Reserved								OFF				
★	Reserved									ON			
	Reserved									OFF			
★	Reserved										ON		
	Reserved										OFF		
★	Reserved											ON	
	Reserved											OFF	
★	Reserved												ON
	Reserved												OFF

★ Manufacture setting

Note.(1) Please reset the bill acceptor after set the dip switch.

(2) Calibration card is needed.

XBA mini-NUO7(NIO3+USD4)(MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(JPSTD)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
★	Reserved		ON		
	Reserved		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
★	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	MDB
BV1	NIO 100	NIO 100	NIO 100	NIO 100
BV2		NIO 500	NIO 500	NIO 500
BV3		NIO 1000	NIO 1000	NIO 1000
BV4		USD 10	USD 10	USD 10
BV5		USD 20	USD 20	USD 20
BV6		USD 50	USD 50	USD 50
BV7		USD 100	USD 100	USD 100

Interface Settings: 2(ICT104V)

	INTERFACE	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT JPSTD Converter board	OFF			
★	Reserved		ON		
	Reserved		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
★	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104U)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
★	Reserved		ON		
	Reserved		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
★	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
★	Reserved		ON		
	Reserved		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
★	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting