

XBA mini-RUB8

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill RUB 10, 50, 100, 200, 500, 1000, 2000, 5000 8bills.

XBA mini dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject RUB 10	ON											
★	Accept RUB 10	OFF											
★	Reject RUB 50 & 100 & 200		ON										
★	Accept RUB 50 & 100 & 200		OFF										
★	Reject RUB 500			ON									
★	Accept RUB 500			OFF									
★	Reject RUB 1000				ON								
★	Accept RUB 1000				OFF								
★	Reject RUB 2000 & 5000					ON							
★	Accept RUB 2000 & 5000					OFF							
★	Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★	Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
★	Stack Banknote when Power-up							ON					
★	Reject Banknote when Power-up							OFF					
★	Reserved								ON				
★	Reserved								OFF				
★	Inhibit Active High									ON			
★	Inhibit Active Low									OFF			
★	Reserved										ON		
★	Reserved										OFF		
★	Interface Timing Conversion	50ms LO / 50ms HI										OFF	OFF
		60ms LO / 300ms HI										ON	OFF
		30ms LO / 50ms HI										OFF	ON
		150ms LO / 150ms HI										ON	ON

★ Manufacture setting

Note : (1) After setting dip switch of the credit pulses,you should reset the bill acceptor again.

(2) Please reset the bill acceptor after set the dip switch.

(3) Dip switches 1 to 5 are only used for pulse protocol.

(4) Calibration card is needed.

(5) When Dip 1 is OFF, 10 RUB = 1 pulse. MDB Mode: When Dip 1 is OFF,Accept 10 RUB
When Dip 1 is ON, 50 RUB = 1 pulse. When Dip 1 is ON,Accept 5000 RUB

XBA mini-RUB8(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / RUB 10 & 50 (Note,5)			OFF	OFF
	5 pulses / RUB 10 & 50 (Note,5)			OFF	ON
	10 pulses / RUB 10 & 50 (Note,5)			ON	OFF
	25 pulses / RUB 10 & 50 (Note,5)			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

	INTERFACE	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT JPSTD converter board	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
★	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(Other)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface	JPSTD	ICT104U	ICT104V	Pulse		MDB	
Bill value				When Dip 1 is ON	When Dip 1 is OFF	When Dip 1 is ON	When Dip 1 is OFF
BV1	RUB 10	RUB 10	RUB 10		RUB 10	RUB 50	RUB 10
BV2		RUB 50	RUB 50	RUB 50	RUB 50	RUB 100	RUB 50
BV3		RUB 100	RUB 100	RUB 100	RUB 100	RUB 500	RUB 100
BV4		RUB 500	RUB 500	RUB 500	RUB 500	RUB1000	RUB 500
BV5		RUB1000	RUB1000	RUB1000	RUB1000	RUB5000	RUB1000
BV6		RUB5000	RUB5000	RUB5000	RUB5000	RUB 200	
BV7		RUB 200	RUB 200	RUB 200	RUB 200	RUB2000	RUB 200
BV8		RUB2000	RUB2000	RUB2000	RUB2000		RUB2000