

XBA mini-ILS3

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill ILS 20, 50, 100 3bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject ILS 20	ON											
★ Accept ILS 20	OFF											
★ Reject ILS 50		ON										
★ Accept ILS 50		OFF										
★ Reject ILS 100			ON									
★ Accept ILS 100			OFF									
Reserved				ON								
★ Reserved				OFF								
Reserved					ON							
★ Reserved					OFF							
Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
Stack Banknote when Power-up							ON					
★ Reject Banknote when Power-up							OFF					
Reserved								ON				
★ Reserved								OFF				
Pulse Mode												
Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
Reserved									ON			
★ Reserved									OFF			
★ Interface Timing Conversion		50ms LO / 50ms HI								OFF	OFF	
		60ms LO / 300ms HI								ON	OFF	
		30ms LO / 50ms HI								OFF	ON	
		150ms LO / 150ms HI								ON	ON	

★ Manufacture setting

After setting dip switch of the credit pulses,you should reset the bill acceptor again.

XBA mini-ILS3(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
Other Mode		OFF		
★ 1 pulse / ILS 10			OFF	OFF
5 pulses / ILS 10			OFF	ON
10 pulses / ILS 10			ON	OFF
20 pulses / ILS 10			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

INTERFACE	SW1	SW2	SW3	SW4
★ Connect with coin changer	ON			
Connect with ICT JPSTD converter board	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
★ ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(Other)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
★ MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1 ILS 20	ILS 20	ILS 20	ILS 20	ILS 20	ILS 20
BV2	ILS 50	ILS 50	ILS 50	ILS 50	ILS 50
BV3	ILS 100	ILS 100	ILS 100	ILS 100	ILS 100