

XBA mini-KZT4

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill KZT 200, 500, 1000, 2000 4bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject KZT 200	ON											
★ Accept KZT 200	OFF											
★ Reject KZT 500		ON										
★ Accept KZT 500		OFF										
★ Reject KZT 1000			ON									
★ Accept KZT 1000			OFF									
★ Reject KZT 2000				ON								
★ Accept KZT 2000				OFF								
★ Reserved				ON								
★ Reserved				OFF								
★ Disable Bill Reject 4 Times BA Stop By 30 Sec					ON							
★ Enable Bill Reject 4 Times BA Stop By 30 Sec					OFF							
★ Stack Banknote when Power-up						ON						
★ Reject Banknote when Power-up						OFF						
★ Reserved							ON					
★ Reserved							OFF					
★ Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ Reserved								ON				
★ Reserved								OFF				
★ Interface Timing Conversion		50ms LO / 50ms HI							OFF	OFF		
		60ms LO / 300ms HI							ON	OFF		
		30ms LO / 50ms HI							OFF	ON		
		150ms LO / 150ms HI							ON	ON		

★ Manufacture setting

After setting dip switch of the credit pulses,you should reset the bill acceptor again.

Note : 1. Calibration card is needed.

XBA mini-KZT4(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
★ 1 pulse / KZT 100			OFF	OFF
2 pulses / KZT 100			OFF	ON
5 pulses / KZT 100			ON	OFF
20 pulses / KZT 100			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	KZT 200	KZT 200	KZT 200	KZT 200	KZT 200
BV2		KZT 500	KZT 500	KZT 500	KZT 500
BV3		KZT 1000	KZT 1000	KZT 1000	KZT 1000
BV4		KZT 2000	KZT 2000	KZT 2000	KZT 2000

Interface Settings: 2(ICT104V)

INTERFACE	SW1	SW2	SW3	SW4
★ Connect with coin changer	ON			
Connect with ICT JPSTD Converter board	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
★ ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(Other)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
★ MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting