

XBA mini-LAK8

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill LAK 500, 1000, 2000, 5000, 10000, 20000, 50000, 100000 8bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject LAK 500 & 1000	ON											
★ Accept LAK 500 & 1000	OFF											
★ Reject LAK 2000 & 5000		ON										
★ Accept LAK 2000 & 5000		OFF										
★ Reject LAK 10000 & 20000			ON									
★ Accept LAK 10000 & 20000			OFF									
★ Reject LAK 50000				ON								
★ Accept LAK 50000				OFF								
★ Reject LAK 100000					ON							
★ Accept LAK 100000					OFF							
★ Disable Bill Reject 4 Times BA Stop By 30 Sec					ON							
★ Enable Bill Reject 4 Times BA Stop By 30 Sec					OFF							
★ Stack Banknote when Power-up						ON						
★ Reject Banknote when Power-up						OFF						
★ Reserved								ON				
★ Reserved								OFF				
★ Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ Reserved									ON			
★ Reserved									OFF			
★ Interface Timing Conversion		50ms LO / 50ms HI								OFF	OFF	
		60ms LO / 300ms HI								ON	OFF	
		30ms LO / 50ms HI								OFF	ON	
		150ms LO / 150ms HI								ON	ON	

★ Manufacture setting

Note : (1) After setting dip switch of the credit pulses,you should reset the bill acceptor again.

(2) Calibration card is needed.

XBA mini-LAK8(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
Other Mode		OFF		
★ 1 pulse / LAK 500			OFF	OFF
2 pulses / LAK 500			OFF	ON
5 pulses / LAK 500			ON	OFF
10 pulses / LAK 500			ON	ON

★ Manufacture setting

Interface Settings: 2(JPSTD)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
★ Pulse Mode		ON		
Other Mode		OFF		
★ MDB Mode			OFF	OFF
★ JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104U)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
★ Pulse Mode		ON		
Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
★ ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

INTERFACE	SW1	SW2	SW3	SW4
★ Connect with coin changer	ON			
Connect with ICT JPSTD converter board	OFF			
★ Pulse Mode		ON		
Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
★ ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 10 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 1	OFF			
Pulse Mode		ON		
Other Mode		OFF		
★ MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	500	500	500	500	500
BV2		1000	1000	1000	1000
BV3		2000	2000	2000	2000
BV4		5000	5000	5000	5000
BV5		10000	10000	10000	10000
BV6		20000	20000	20000	20000
BV7		50000	50000	50000	50000
BV8		100000	100000	100000	100000