

XBA mini-PHP6

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104U/ICT104V)

Supported bill PHP 20, 50, 100, 200, 500, 1000 6bills.

XBA mini dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject PHP 20	ON											
★	Accept PHP 20	OFF											
	Reject PHP 50		ON										
★	Accept PHP 50		OFF										
	Reject PHP 100			ON									
★	Accept PHP 100			OFF									
	Reject PHP 200				ON								
★	Accept PHP 200				OFF								
	Reject PHP 500 & 1000					ON							
★	Accept PHP 500 & 1000					OFF							
	Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★	Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
	Stack Banknote when Power-up							ON					
★	Reject Banknote when Power-up							OFF					
	Reserved								ON				
★	Reserved								OFF				
	Inhibit Active High									ON			
★	Inhibit Active Low									OFF			
	MDB Special Mode	(No Error Code)(MDB Only)									ON		
★	MDB Normal Mode										OFF		
★	Interface Timing Conversion	50ms LO / 50ms HI										OFF	OFF
		60ms LO / 300ms HI										ON	OFF
		30ms LO / 50ms HI										OFF	ON
		150ms LO / 150ms HI										ON	ON

★ Manufacture setting

Note : (1) After setting dip switch of the credit pulses,you should reset the bill acceptor again.
(2) Calibration card is needed.

XBA mini-PHP6(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / PHP 10			OFF	OFF
	5 pulses / PHP 10			OFF	ON
	10 pulses / PHP 10			ON	OFF
	20 pulses / PHP 10			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(Other)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

	FUNCTION	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT JPSTD Converter board	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
★	ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	PHP 20	PHP 20	PHP 20	PHP 20	PHP 20
BV2		PHP 50	PHP 50	PHP 50	PHP 50
BV3		PHP 100	PHP 100	PHP 100	PHP 100
BV4		PHP 500	PHP 500	PHP 200	PHP 200
BV5		PHP 1000	PHP 1000	PHP 500	PHP 500
BV6		PHP 200	PHP 200	PHP 1000	PHP 1000