

XBA mini-QAR3

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104U/ICT104V)

Supported bill QAR 1, 5, 10 3bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject QAR 1	ON											
★ Accept QAR 1	OFF											
★ Reject QAR 5		ON										
★ Accept QAR 5		OFF										
★ Reject QAR 10			ON									
★ Accept QAR 10			OFF									
★ Reserved				ON								
★ Reserved				OFF								
★ Reserved					ON							
★ Reserved					OFF							
★ Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
★ Stack Banknote when Power-up							ON					
★ Reject Banknote when Power-up							OFF					
★ Reserved								ON				
★ Reserved								OFF				
★ Inhibit Active High									ON			
★ Inhibit Active Low									OFF			
★ Reserved										ON		
★ Reserved										OFF		
★ Interface Timing Conversion		50ms LO / 50ms HI									OFF	OFF
		60ms LO / 300ms HI									ON	OFF
		30ms LO / 50ms HI									OFF	ON
		150ms LO / 150ms HI									ON	ON

★ Manufacture setting

Note : (1) After setting dip switch of the credit pulses,you should reset the bill acceptor again.

XBA mini-QAR3(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / QAR 1 · 5(Note.2) · 10(Note.2)			OFF	OFF
	2 pulses / QAR 1 · 5(Note.2) · 10(Note.2)			OFF	ON
	4 pulses / QAR 1 · 5(Note.2) · 10(Note.2)			ON	OFF
	20 pulses / QAR 1 · 5(Note.2) · 10(Note.2)			ON	ON

★ Manufacture setting

Note : 1. Calibration card is needed.

2. In pulse mode:

When only reject QAR 1: 1 pulse per QAR 5

When only accept QAR 10: 1 pulse per QAR 10

Interface Settings: 2(Other)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	QAR 1	QAR 1	QAR 1	QAR 1	QAR 1
BV2		QAR 5	QAR 5	QAR 5	QAR 5
BV3		QAR 10	QAR 10	QAR 10	QAR 10

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

	FUNCTION	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT VCCS Converter board	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
★	ICT104V Mode			ON	ON

★ Manufacture setting