

V7E/LX7-EGP2

V7E/LX7 Option Switch Settings: 1(Pulse/ICT104U/M.D.B)

Supported bill EGP 5, 10 2bills.

V7E dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject EGP 5	ON											
★	Accept EGP 5	OFF											
	Reject EGP 10		ON										
★	Accept EGP 10		OFF										
	Reserved			ON									
★	Reserved			OFF									
	Reserved				ON								
★	Reserved			OFF									
	Reserved				ON								
★	Reserved				OFF								
	Reserved					ON							
★	Reserved					OFF							
	Harness Disable						ON						
★	Harness Enable						OFF						
	Inhibit Active High							ON					
★	Inhibit Active Low							OFF					
★	1 pulse / EGP 5								OFF	OFF			
	2 pulse / EGP 5								ON	OFF			
	5 pulse / EGP 5								OFF	ON			
	20 pulse / EGP 5								ON	ON			
★	Pulse Speed	50ms on / 50ms off									OFF	OFF	
		60ms on / 300ms off									ON	OFF	
		30ms on / 50ms off									OFF	ON	
		150ms on / 150ms off									ON	ON	

★ Manufacture setting

◆ Note : (1) Reset the bill acceptor after setting the dip switch.

(2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.

V7E/LX7-EGP2(Pulse/ICT104U/M.D.B)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
	ICT104U Interface		OFF	ON	
★	Pulse Mode		ON	OFF	
	M.D.B Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
	Reserved				OFF

DIP SWITCHES SETTING : 2(ICT104U)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
★	ICT104U Interface		OFF	ON	
	Pulse Mode		ON	OFF	
	M.D.B Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

Currency Assign Data

Interface Bill value	Pulse	MDB	ICT104U
BV1	EGP 5	EGP 5	EGP 5
BV2	EGP 10	EGP 10	EGP 10

DIP SWITCHES SETTING : 2(M.D.B)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	ICT Interface		OFF	ON	
	Pulse Mode		ON	OFF	
★	M.D.B Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

◆ Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.