

# HNL5

## P70/P5 DIP SWITCHES SETTING : 1(Parallel A1 Protocol)

Supported bill L 10, 20, 50, 100, 500 5bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10	
★	Reserved	OFF	OFF	OFF								
		OFF	OFF	ON								
		OFF	ON	OFF								
		OFF	ON	ON								
		ON	OFF	OFF								
		ON	OFF	ON								
		ON	ON	OFF								
		ON	ON	ON								
					ON							
★					OFF							
						ON						
★						OFF						
★	Accept L 10						ON					
	Reject L 10						OFF					
★	Accept L 20								ON			
	Reject L 20								OFF			
★	Accept L 50									ON		
	Reject L 50									OFF		
★	Accept L 100										ON	
	Reject L 100										OFF	
★	Accept L 500											ON
	Reject L 500											OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

## DIP SWITCHES SETTING : 2

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
★			ON		
			OFF		
★				ON	
★				OFF	
★	Ignore Sensor Problem(Note 1)				ON
★	Acknowledge Sensor Problem (Note 2)				OFF

★ Manufacture setting

Note : (1) Sensor 6 problem occurred ==>> BA will be still in working order.

(The face LED will be flashing in short green about 2 seconds everytime you restart BA.)

(2) BA will stop working when it acknowledges Sensor 6 problem occurred.

(The face LED will be flashing in red.)