TAO-A/V-ARS6

TAO-A/V Option Switch Settings: 1(Pulse/RS232 A0) Supported bill ARS 2, 5, 10, 20, 50, 100 6bills.

TAO-A/V dip-switch settings and functions:

| | FUNCTION | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW1 | SW2 | SW3 | SW4 |
|---|-----------------------------|---------------------|-------|-------|-------|-----|-----|-----|-----|-----|-----|-----|-----|
| | Reject ARS 2 & 5 | ON | | | | | | | | | | | |
| * | Accept ARS 2 & 5 | OFF | | | | | | | | | | | |
| | Reject ARS 10 | | ON | | | | | | | | | | |
| * | Accept ARS 10 | | OFF | | | | | | | | | | |
| | Reject ARS 20 | | | ON | | | | | | | | | |
| * | Accept ARS 20 | | | OFF | | | | | | | | | |
| | Reject ARS 50 | | | | ON | | | | | | | | |
| * | Accept ARS 50 | | | | OFF | | | | | | | | |
| | Reject ARS 100 | | | | | ON | | | | | | | |
| * | Accept ARS 100 | | | | | OFF | | | | | | | |
| | High Acceptance | | | | | | ON | | | | | | |
| * | High Security | | | | | | OFF | | | | | | |
| | Harness Disable | | | | | | | ON | | | | | |
| * | Harness Enable | | | | | | | OFF | | | | | |
| | Inhibit Active High | | | | | | | | ON | | | | |
| * | Inhibit Active Low | | | | | | | | OFF | | | | |
| * | 1 pulse / ARS 1 | | | | | | | | | OFF | OFF | | |
| | 2 pulses / ARS 1 | | | | | | | | | ON | OFF | | |
| | 4 pulses / ARS 1 | | | | | | | | | OFF | ON | | |
| | 20 pulses / ARS 1 | | | | | | | | | ON | ON | | |
| * | | 50ms on / 50ms off | | | | | | | OFF | OFF | | | |
| | Interface Timing Conversion | 60ms on / 300ms off | | | | | | | ON | OFF | | | |
| | | 30ms on / 50ms off | | | | | | | OFF | ON | | | |
| | | 150m | ns on | / 150 | ms of | f | | | | | | ON | ON |

[★] Manufacture setting

TAO-A/V-ARS6(RS232 A0/Pulse)

Interface Settings: 3(Pulse)

| | INTERFACE | SW1 | SW2 | SW3 | SW4 |
|---|--------------------------|-----|-----|-----|-----|
| * | Credit-Pulse Normal HIGH | ON | | | |
| | Credit-Pulse Normal LOW | OFF | | | |
| * | Pulse Mode | | ON | | |
| | RS232 A0 Protocol Mode | | OFF | | |
| | Reserved | | | ON | |
| | Reserved | | | OFF | |
| | Reserved | | | | ON |
| | Reserved | | | | OFF |

[★] Manufacture setting

Interface Settings: 3(RS232 A0)

| | INTERFACE | SW1 | SW2 | SW3 | SW4 |
|---|------------------------|-----|-----|-----|-----|
| | Reserved | ON | | | |
| | Reserved | OFF | | | |
| | Pulse Mode | | ON | | |
| * | RS232 A0 Protocol Mode | | OFF | | |
| | Reserved | | | ON | |
| | Reserved | | | OFF | |
| | Reserved | | | | ON |
| | Reserved | | | | OFF |

[★] Manufacture setting

Note: (1) Default setting

(2) RS232 A0 INFORMATION

| BillType Data | | | | | | |
|---------------|--------------|--|--|--|--|--|
| Code | Denomination | | | | | |
| 1 Reserved | | | | | | |
| 2 | ARS 2 | | | | | |
| 3 | ARS 5 | | | | | |
| 4 | ARS 10 | | | | | |
| 5 | ARS 20 | | | | | |
| 6 | ARS 50 | | | | | |
| 7 | ARS 100 | | | | | |