

TAO-A.V-DOP6

TAO-A.V Option Switch Settings: 1(Pulse/ICT104V/ICT104U/MDB)

Supported bill DOP 20, 50, 100, 200, 500, 1000 6bills.

TAO-V dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject DOP 20 (Note.4)	ON											
★ Accept DOP 20 (Note.4)	OFF											
★ Reject DOP 50		ON										
★ Accept DOP 50		OFF										
★ Reject DOP 100			ON									
★ Accept DOP 100			OFF									
★ Reject DOP 200 & 500				ON								
★ Accept DOP 200 & 500				OFF								
★ Reject DOP 1000					ON							
★ Accept DOP 1000					OFF							
★ Reserved					ON							
★ Reserved					OFF							
★ Pulse Mode	Other Mode											
★ Harness Disable	BA stops working when fishing						ON					
★ Harness Enable	Normal						OFF					
★ Inhibit Active High							ON					
★ Inhibit Active Low							OFF					
★ 1 pulse / DOP 10 & 50	(Note.4)							OFF	OFF			
★ 2 pulses / DOP 10 & 50	(Note.4)							ON	OFF			
★ 5 pulses / DOP 10 & 50	(Note.4)							OFF	ON			
★ 10 pulses / DOP 10 & 50	(Note.4)							ON	ON			
★ Interface Timing Conversion	50ms LO / 50ms HI									OFF	OFF	
	60ms LO / 300ms HI									ON	OFF	
	30ms LO / 50ms HI									OFF	ON	
	150ms LO / 150ms HI									ON	ON	

★ Manufacture setting

◆ Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

(4) Pulse: SW1 Dip1 -> OFF, \$20=2 pulses, \$50=5 pulses, \$100=10 pulses, \$200=20 pulses, \$500=50 pulses, \$1000=100 pulses. (Based on 10 DOP per pulse)

SW1 Dip1 -> ON, \$50=1 pulse, \$100=2 pulses, \$200=4 pulses, \$500=10 pulses,

\$1000=20 pulses. (Based on 50 DOP per pulse)

Appendix

TAO-A.V-DOP6(Pulse/ICT104V/ICT104U/MDB)

Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON	OFF	
ICT104V Interface		ON	ON	
ICT104U Interface		OFF	ON	
MDB Interface		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

Interface Settings: 2(ICT104V)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
★ Reserved	OFF			
Pulse Mode		ON	OFF	
★ ICT104V Interface		ON	ON	
★ ICT104U Interface		OFF	ON	
MDB Interface		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	Pulse		MDB	ICT104V	ICT104U
	SW1 Dip 1 is OFF	SW1 Dip 1 is ON			
BV1	DOP 20		DOP 20	DOP 20	DOP 20
BV2	DOP 50	DOP 50	DOP 50	DOP 50	DOP 50
BV3	DOP 100	DOP 100	DOP 100	DOP 100	DOP 100
BV4	DOP 200	DOP 200	DOP 200	DOP 200	DOP 200
BV5	DOP 500	DOP 500	DOP 500	DOP 500	DOP 500
BV6	DOP 1000	DOP 1000	DOP 1000	DOP 1000	DOP 1000

Interface Settings: 2(ICT104U)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
★ Reserved	OFF			
Pulse Mode		ON	OFF	
★ ICT104V Interface		ON	ON	
★ ICT104U Interface		OFF	ON	
MDB Interface		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting

TAO-V-DOP6

Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON	OFF	
★ ICT104V Interface		ON	ON	
★ ICT104U Interface		OFF	ON	
★ MDB Interface		OFF	OFF	
★ Reserved				ON
				OFF

★ Manufacture setting