

## XBA mini-BHD2

### XBA mini Option Switch Settings: 1(Pulse/MDB/ICT104U/ICT104V)

# Supported bill BHD 0.5, 1 2bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject BHD 0.5	ON											
★ Accept BHD 0.5	OFF											
★ Reject BHD 1		ON										
★ Accept BHD 1		OFF										
★ Reserved			ON									
★ Reserved			OFF									
★ Reserved				ON								
★ Reserved				OFF								
★ Reserved					ON							
★ Reserved					OFF							
★ Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
★ Stack Banknote when Power-up							ON					
★ Reject Banknote when Power-up							OFF					
★ Reserved								ON				
★ Reserved								OFF				
★ Inhibit Active High									ON			
★ Inhibit Active Low									OFF			
★ Reserved										ON		
★ Reserved										OFF		
★ Interface Timing Conversion	50ms LO / 50ms HI								OFF	OFF		
	60ms LO / 300ms HI								ON	OFF		
	30ms LO / 50ms HI								OFF	ON		
	150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

After setting dip switch of the credit pulses,you should reset the bill acceptor again.

Note : 1.Calibration card is needed.

## XBA mini-BHD2(Pulse/MDB/ICT104U/ICT104V)

### Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
★ 1 pulse / BHD 0.5			OFF	OFF
2 pulses / BHD 0.5			OFF	ON
4 pulses / BHD 0.5			ON	OFF
20 pulses / BHD 0.5			ON	ON

★ Manufacture setting

### Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 3	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 1	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
★ MDB Mode			OFF	OFF
Reserved			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

### Interface Settings: 2(Other)

FUNCTION	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
Reserved			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

### Interface Settings: 2(ICT104V)

FUNCTION	SW1	SW2	SW3	SW4
★ Connect with coin changer	ON			
Connect with ICT JPSTD Converter board	OFF			
Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
Reserved			OFF	ON
ICT104U Mode			ON	OFF
★ ICT104V Mode			ON	ON

★ Manufacture setting

## Currency Assign Data

Interface Bill value	Pulse	MDB	ICT104U	ICT104V
BV1	BHD 0.5	BHD 0.5	BHD 0.5	BHD 0.5
BV2	BHD 1	BHD 1	BHD 1	BHD 1