

P77-CZK6

P77 DIP SWITCHES SETTING : 1(Pulse/MDB)

Supported bill CZK 100, 200, 500, 1000, 2000, 5000 6bills.

With stacker CZK 100, 200, 500, 1000, 2000 5bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
★	1 Pulse / CZK 50	OFF	OFF	OFF							
	2 Pulse / CZK 50	OFF	OFF	ON							
	3 Pulse / CZK 50	OFF	ON	OFF							
	4 Pulse / CZK 50	OFF	ON	ON							
	5 Pulse / CZK 50	ON	OFF	OFF							
	10 Pulse / CZK 50	ON	OFF	ON							
	20 Pulse / CZK 50	ON	ON	OFF							
	100 Pulse / CZK 50	ON	ON	ON							
	Fast output Pulse Lo= 50ms Hi=100ms				ON						
★	Slow output Pulse Lo= 50ms Hi=300ms				OFF						
	Inhibit level Active Low				ON						
★	Inhibit level Active High				OFF						
★	Accept CZK 100				ON						
	Reject CZK 100				OFF						
★	Accept CZK 200 & 500				ON						
	Reject CZK 200 & 500				OFF						
★	Accept CZK 1000				ON						
	Reject CZK 1000				OFF						
★	Accept CZK 2000				ON						
	Reject CZK 2000				OFF						
★	Accept CZK 5000				ON						
	Reject CZK 5000				OFF						

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

P77-CZK6(Pulse/MDB)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal High	ON			
	Credit-Pulse Normal Low	OFF			
★	Pulse Mode		ON		
	MDB Interface		OFF		
★	Harness Disable			ON	
	Harness Enable			OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 & 3 are only used for pulse protocol.

DIP SWITCHES SETTING : 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
★	Pulse Mode		ON		
	MDB Interface		OFF		
★	Reserved			ON	
				OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

Currency Assign Data

Interface Bill value	MDB	Pulse
BV1		
BV2	CZK 100	CZK 100
BV3	CZK 200	CZK 200
BV4	CZK 500	CZK 500
BV5	CZK 1000	CZK 1000
BV6	CZK 2000	CZK 2000
BV7	CZK 5000	CZK 5000