

TAO-A.V-AED5

TAO-A.V Option Switch Settings: 1(Pulse/ICT104V/ICT104U/MDB)

Supported bill AED 5, 10, 20, 50, 100 5bills.

TAO-V dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject AED 5	ON											
★ Accept AED 5	OFF											
★ Reject AED 10		ON										
★ Accept AED 10		OFF										
★ Reject AED 20			ON									
★ Accept AED 20			OFF									
★ Reject AED 50				ON								
★ Accept AED 50				OFF								
★ Reject AED 100					ON							
★ Accept AED 100					OFF							
★ Reserved					ON							
★ Reserved					OFF							
Pulse Mode	Other Mode											
★ Harness Disable	BA stops working when fishing				ON							
★ Harness Enable	Normal				OFF							
★ Inhibit Active High							ON					
★ Inhibit Active Low							OFF					
★ 1 pulse / AED 5								OFF	OFF			
★ 2 pulses / AED 5								ON	OFF			
★ 5 pulses / AED 5								OFF	ON			
★ 10 pulses / AED 5								ON	ON			
★ Interface Timing Conversion	50ms HI / 50ms LO									OFF	OFF	
	300ms HI / 60ms LO									ON	OFF	
	50ms HI / 30ms LO									OFF	ON	
	150ms HI / 150ms LO									ON	ON	

★ Manufacture setting

◆ Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

(Please refer to "SW1" setting.)

BV1=AED 5, BV2=AED 10, BV3=AED 20, BV4=AED 50, BV5=AED 100

TAO-A.V-AED5(Pulse/ICT104V/ICT104U/MDB)

Interface Settings: 2(Pulse) Currency Assign Data

INTERFACE	SW1	SW2	SW3	SW4	Interface Bill value	ICT	Pulse	MDB
★ Credit-Pulse Normal HIGH	ON				BV1	AED 5	AED 5	AED 5
Credit-Pulse Normal LOW	OFF				BV2	AED 10	AED 10	AED 10
★ Pulse Mode		ON	OFF		BV3	AED 20	AED 20	AED 20
ICT104U Mode		OFF	OFF		BV4	AED 50	AED 50	AED 50
ICT104V Mode		OFF	ON		BV5	AED 100	AED 100	AED 100
MDB Mode		ON	ON					
★ Reserved				ON				
				OFF				

★ Manufacture setting

Interface Settings: 2(ICT104U/ICT104V)

INTERFACE	SW1	SW2	SW3	SW4	INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON				★ Reserved	ON			
Reserved	OFF				Reserved	OFF			
Pulse Mode		ON	OFF		Pulse Mode		ON	OFF	
★ ICT104U Mode		OFF	OFF		★ ICT104U Mode		OFF	OFF	
ICT104V Mode		OFF	ON		★ ICT104V Mode		OFF	ON	
MDB Mode		ON	ON		MDB Mode		ON	ON	
★ Reserved				ON	★ Reserved				ON
				OFF					OFF

★ Manufacture setting

★ Manufacture setting

TAO-V-AED5

Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
Pulse Mode		ON	OFF	
ICT104U Mode		OFF	OFF	
ICT104V Mode		OFF	ON	
★ MDB Interface		ON	ON	
★ Reserved				ON
				OFF

★ Manufacture setting