# XBA-AOA4

XBA Option Switch Settings(Pulse/MDB/ICT104U/ICT104V)

Supported bill AOA 200, 500, 1000, 2000   4bills.

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
Reject AOA 200	ON							
★ Accept AOA 200	OFF							
Reject AOA 500		ON						
★ Accept AOA 500		OFF						
Reject AOA 1000			ON					
★ Accept AOA 1000			OFF					
Reject AOA 2000				ON				
★ Accept AOA 2000				OFF				
Reserved					ON			
★ Reserved					OFF			
Disable Bill Reject 4 Times BA Stop By 30 Sec						ON		
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF		
Stack Banknote when Power-up							ON	
★ Reject Banknote when Power-up							OFF	
Reserved								ON
★ Reserved								OFF

This dip switch is located at the side of XBA.

Currency Assign Data

Interface / Bill value	ICT104U	ICT104V	Pulse	MDB
BV1	AOA 200	AOA 200	AOA 200	AOA 200
BV2	AOA 500	AOA 500	AOA 500	AOA 500
BV3	AOA 1000	AOA 1000	AOA 1000	AOA 1000
BV4	AOA 2000	AOA 2000	AOA 2000	AOA 2000

XBA-AOA4 (Pulse/MDB/ICT104U/ICT104V)

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
Inhibit Active HIGH	ON							
★ Inhibit Active LOW	OFF							
Reserved		ON						
★ Reserved		OFF						
Reserved			ON					
★ Reserved			OFF					
Reserved				ON				
★ Reserved				OFF				

Pulse Mode	MDB Mode	ICT104V Mode	SW6
★ Credit-Pulse Normal HIGH	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	Connect with coin changer	ON
Credit-Pulse Normal LOW	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	Connect with ICT VCCS converter board	OFF

	SW7
★ Pulse Mode	ON
Other Mode	OFF

Pulse Mode	Other Mode	SW7	SW8
★ 1 pulse / AOA 100	MDB Mode	OFF	OFF
2 pulse / AOA 100	Reserved	OFF	ON
5 pulse / AOA 100	ICT104U Mode	ON	OFF
20 pulse / AOA 100	ICT104V Mode	ON	ON

This dip switch is located on the CPU board, remove the CPU board cover first.

(1)

DIP Switch

★ Manufacture setting

Affer setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note：1.Calibration card is needed.

2.No sleep function.