

## XBA mini-AOA4

### XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill AOA 200, 500, 1000, 2000 4bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject AOA 200	ON											
★ Accept AOA 200	OFF											
★ Reject AOA 500		ON										
★ Accept AOA 500		OFF										
★ Reject AOA 1000			ON									
★ Accept AOA 1000			OFF									
★ Reject AOA 2000				ON								
★ Accept AOA 2000				OFF								
★ Reserved					ON							
★ Reserved					OFF							
★ Disable Bill Reject 4 Times BA Stop By 30 Sec					ON							
★ Enable Bill Reject 4 Times BA Stop By 30 Sec					OFF							
★ Stack Banknote when Power-up						ON						
★ Reject Banknote when Power-up						OFF						
★ Reserved							ON					
★ Reserved							OFF					
★ Inhibit Active High								ON				
★ Inhibit Active Low								OFF				
★ Reserved									ON			
★ Reserved									OFF			
★ Interface Timing Conversion	50ms LO / 50ms HI								OFF		OFF	
	60ms LO / 300ms HI								ON		OFF	
	30ms LO / 50ms HI								OFF		ON	
	150ms LO / 150ms HI								ON		ON	

★ Manufacture setting

Note : 1. Calibration card is needed.

## XBA mini-AOA4(Pulse/MDB/JPSTD/ICT104V/ICT104U)

### Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
★ 1 pulse / AOA 100			OFF	OFF
2 pulses / AOA 100			OFF	ON
5 pulses / AOA 100			ON	OFF
20 pulses / AOA 100			ON	ON

★ Manufacture setting

### Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	AOA 200	AOA 200	AOA 200	AOA 200	AOA 200
BV2		AOA 500	AOA 500	AOA 500	AOA 500
BV3		AOA 1000	AOA 1000	AOA 1000	AOA 1000
BV4		AOA 2000	AOA 2000	AOA 2000	AOA 2000

### Interface Settings: 2(ICT104V)

INTERFACE	SW1	SW2	SW3	SW4
★ Connect with coin changer	ON			
Connect with ICT JPSTD Converter board	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
★ ICT104V Mode			ON	ON

★ Manufacture setting

### Interface Settings: 2(ICT104U)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
★ ICT104U Mode			ON	OFF
★ ICT104V Mode			ON	ON

★ Manufacture setting

### Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
★ MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting