#### A7/V7-RUR6

## **A7/V7 Option Switch Settings:1(Pulse/ccTalk)**

Supported bill Ruble 50, 100, 200, 500, 1000, 2000 6bills.

A7/V7 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
	Reject Ruble 50	ON											
*	Accept Ruble 50	OFF											
	Reject Ruble 100		ON										
*	Accept Ruble 100		OFF										
	Reject Ruble 200			ON									
*	Accept Ruble 200			OFF									
	Reject Ruble 500				ON								
*	Accept Ruble 500				OFF								
	Reject Ruble 1000 & 2000					ON							
*	Accept Ruble 1000 & 2000					OFF							
	Reserved						ON						
*	Reserved						OFF						
	Harness Disable							ON					
*	Harness Enable	OFF											
	Inhibit Active High	ON											
*	Inhibit Active Low	OFF											
*	1 pulse / Ruble 50	OFF					OFF	OFF					
	5 pulse / Ruble 50							ON	OFF				
	10 pulse / Ruble 50						OFF	ON					
	50 pulse / Ruble 50						ON	ON					
*		50ms LO / 50ms HI									OFF	OFF	
	Pulse Speed	60ms LO / 300ms HI				11						ON	OFF
		30ms LO / 50ms HI				11						OFF	ON
		150n	ns LO	/ 150	)ms F	11						ON	ON

Factory configuration has all switches in the OFF position.

Note: (1) Reset the bill acceptor after setting the dip switch.

- (2) SW7 and SW8 of the 8-switch DIP and the 4-switch DIP are for pulse protocol only.
- (3) cctalk Parameters Restore Switch

Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

#### \_Appendix

### A7/V7-RUR6(Pulse/ccTalk)

# **Interface Settings: 2(Pulse)**

	INTERFACE	SW1	SW2	SW3	SW4
*	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
*	Pulse Mode		ON		
	ccTalk Interface Mode		OFF		
*				ON	
	Reserved			OFF	
			ON		
*			OFF		

# **Currency Assign Data**

Interface Bill value	Pulse	ccTalk		
BV1				
BV2	Rubles 50	Rubles 50		
BV3	Rubles 100	Rubles 100		
BV4	Rubles 500	Rubles 500		
BV5	Rubles 1000	Rubles 1000		
BV6	Rubles 200	Rubles 200		
BV7	Rubles 2000	Rubles 2000		

## **Interface Settings: 2(ccTalk)**

	INTERFACE	SW1	SW2	SW3	SW4
*	Reserved	ON			
	Neserved	OFF			
	Pulse Mode		ON		
*	ccTalk Interface Mode		OFF		
•	ccTalk Parameters Restore Switch ( Please see Note.3 for detail) (ccTalk only)			ON	
*	Reserved			OFF	
	Reserved	·	ON		
*	Neserved		OFF		

- ★ Manufacture setting
- ▲ Note:3 cctalk Parameters Restore Switch

Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.