

V7E/LX7-BYN4

V7E/LX7 Option Switch Settings: 1(Pulse/ICT104U/M.D.B)

Supported bill Ruble 5, 10, 20, 50 4bills.

V7E dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject Ruble 5	ON											
	Accept Ruble 5	OFF											
★	Reject Ruble 10		ON										
★	Accept Ruble 10		OFF										
★	Reject Ruble 20			ON									
★	Accept Ruble 20			OFF									
★	Reject Ruble 50				ON								
★	Accept Ruble 50				OFF								
	Reserved				ON								
★	Reserved				OFF								
★	Reserved					ON							
★	Reserved					OFF							
	Pulse Mode	Other Mode											
★	Harness Disable	BA stops working when fishing						ON					
★	Harness Enable	Normal						OFF					
★	Inhibit Active High							ON					
★	Inhibit Active Low							OFF					
★	1 pulse / Ruble 5							OFF	OFF				
	5 pulse / Ruble 5							ON	OFF				
	10 pulse / Ruble 5							OFF	ON				
	50 pulse / Ruble 5							ON	ON				
★	Pulse Speed	50ms LO / 50ms HI								OFF	OFF		
		60ms LO / 300ms HI								ON	OFF		
		30ms LO / 50ms HI								OFF	ON		
		150ms LO / 150ms HI								ON	ON		

★ Manufacture setting

◆ Note : (1) Default setting.

(2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

(3) Remove the front cover and the dip-switch in on the CPU board.

V7E/LX7-BYN4(Pulse/ICT104U/M.D.B)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Mode		ON	OFF	
	ICT104U Interface		OFF	ON	
	MDB Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

DIP SWITCHES SETTING : 2(ICT104U)

	FUNCTION	SW1	SW2	SW3	SW4
★	Reserved	ON			
		OFF			
	Pulse Mode		ON	OFF	
★	ICT104U Interface		OFF	ON	
	MDB Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

Currency Assign Data

Interface Bill value	ICT104U	Pulse	MDB
BV1	Ruble 5	Ruble 5	Ruble 5
BV2	Ruble 10	Ruble 10	Ruble 10
BV3	Ruble 20	Ruble 20	Ruble 20
BV4	Ruble 50	Ruble 50	Ruble 50

DIP SWITCHES SETTING : 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON	OFF	
	ICT Interface		OFF	ON	
★	MDB Interface		ON	ON	
	Reserved		OFF	OFF	
★	Reserved				ON
					OFF

★ Manufacture setting

Note 1: Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.

2: Remove the front cover and the dip-switch in on the CPU board.