

XBA mini-UAH6

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill UAH 1, 2, 5, 10, 20, 50 6bills.

XBA mini dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject UAH 1 & 2	ON											
★	Accept UAH 1 & 2	OFF											
★	Reject UAH 5		ON										
★	Accept UAH 5		OFF										
★	Reject UAH 10			ON									
★	Accept UAH 10			OFF									
★	Reject UAH 20				ON								
★	Accept UAH 20				OFF								
★	Reject UAH 50					ON							
★	Accept UAH 50					OFF							
★	Disable Bill Reject 4 Times BA Stop By 30 Sec					ON							
★	Enable Bill Reject 4 Times BA Stop By 30 Sec					OFF							
★	Stack Banknote when Power-up						ON						
★	Reject Banknote when Power-up						OFF						
★	Reserved							ON					
★	Reserved							OFF					
★	Inhibit Active High								ON				
★	Inhibit Active Low								OFF				
★	Reserved									ON			
★	Reserved									OFF			
★	Interface Timing Conversion	50ms LO / 50ms HI						OFF		OFF			
		60ms LO / 300ms HI						ON		OFF			
		30ms LO / 50ms HI						OFF		ON			
		150ms LO / 150ms HI						ON		ON			

★ Manufacture setting

After setting dip switch of the credit pulses, you should reset the bill acceptor again.

Note : (1) Dip switches 1 to 5 are only used for pulse protocol.

(2) Calibration card is needed.

XBA mini-UAH6(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / UAH 1			OFF	OFF
	5 pulses / UAH 1			OFF	ON
	10 pulses / UAH 1			ON	OFF
	25 pulses / UAH 1			ON	ON

★ Manufacture setting

Interface Settings: 2(Other)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserve	ON			
	Reserve	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	ICT104U	ICT104V	JPSTD	Pulse	MDB
BV1	UAH 1	UAH 1	UAH 1	UAH 1	UAH 1
BV2	UAH 2	UAH 2		UAH 2	UAH 2
BV3	UAH 5	UAH 5		UAH 5	UAH 5
BV4	UAH 10	UAH 10		UAH 10	UAH 10
BV5	UAH 20	UAH 20		UAH 20	UAH 20
BV6	UAH 50	UAH 50		UAH 50	UAH 50

Interface Settings: 2(ICT104V)

	INTERFACE	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT JPSTD Converter board	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
★	ICT104V Mode			ON	ON

★ Manufacture setting