

XBA mini-BDT5

XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill BDT 10, 20, 50, 100, 500 5bills.

XBA mini dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★	Reject BDT 10	ON											
	Accept BDT 10	OFF											
★	Reject BDT 20		ON										
	Accept BDT 20		OFF										
★	Reject BDT 50			ON									
	Accept BDT 50			OFF									
★	Reject BDT 100				ON								
	Accept BDT 100				OFF								
★	Reject BDT 500					ON							
	Accept BDT 500					OFF							
★	Disable Bill Reject 4 Times BA Stop By 30 Sec					ON							
	Enable Bill Reject 4 Times BA Stop By 30 Sec					OFF							
★	Stack Banknote when Power-up							ON					
	Reject Banknote when Power-up							OFF					
★	Reserved								ON				
	Reserved								OFF				
★	Inhibit Active High								ON				
	Inhibit Active Low								OFF				
★	Reserved									ON			
	Reserved									OFF			
★	Interface Timing Conversion	50ms LO / 50ms HI										OFF	OFF
		60ms LO / 300ms HI										ON	OFF
		30ms LO / 50ms HI										OFF	ON
		150ms LO / 150ms HI										ON	ON

★ Manufacture setting

After setting dip switch of the credit pulses,you should reset the bill acceptor again.

Note : (1) Calibration card is needed.

XBA mini-BDT5(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Interface Settings: 2(Pulse)

	INTERFACE	SW1	SW2	SW3	SW4
★	Credit-Pulse Normal HIGH	ON			
	Credit-Pulse Normal LOW	OFF			
★	Pulse Mode		ON		
	Other Mode		OFF		
★	1 pulse / BDT 10			OFF	OFF
	2 pulses / BDT 10			OFF	ON
	5 pulses / BDT 10			ON	OFF
	10 pulses / BDT 10			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

	FUNCTION	SW1	SW2	SW3	SW4
★	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
★	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(Other)

	INTERFACE	SW1	SW2	SW3	SW4
★	Reserved	ON			
	Reserved	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
	ICT104V Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(ICT104V)

	INTERFACE	SW1	SW2	SW3	SW4
★	Connect with coin changer	ON			
	Connect with ICT JPSTD Converter board	OFF			
	Pulse Mode		ON		
★	Other Mode		OFF		
	MDB Mode			OFF	OFF
	JPSTD Mode			OFF	ON
	ICT104U Mode			ON	OFF
★	ICT104V Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	BDT 10	BDT 10	BDT 10	BDT 10	BDT 10
BV2		BDT 20	BDT 20	BDT 20	BDT 20
BV3		BDT 50	BDT 50	BDT 50	BDT 50
BV4		BDT 100	BDT 100	BDT 100	BDT 100
BV5		BDT 500	BDT 500	BDT 500	BDT 500