V7E/LX7-B0B4

V7E/LX7 Option Switch Settings: 1(Pulse/ICT104U/MDB/RS232 A0) Supported bill BOB 10, 20, 50, 100 4bills.

V7E/LX7 dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
	Reject BOB 10	ON											
*	Accept BOB 10	OFF											
	Reject BOB 20		ON										
*	Accept BOB 20		OFF										
	Reject BOB 50			ON									
*	Accept BOB 50			OFF									
	Reject BOB 100				ON								
*	Accept BOB 100				OFF								
	Reserved					ON							
*	Reserved					OFF							
	Reserved						ON						
*	Reserved	OFF											
	Pulse Mode	Other Mode											
	Harness Disable	BA stops working when fishing ON											
*	Harness Enable			Nor	mal			OFF					
	Inhibit Active High								ON				
*	Inhibit Active Low								OFF				
*	1 pulse / BOB 10	OFF OF					OFF						
	2 pulses / BOB 10	ON OFF						OFF					
	4 pulses / BOB 10	OFF ON											
	20 pulses / BOB 10									ON	ON		
*		50ms LO / 50ms HI 60ms LO / 300ms HI					OFF	OFF					
	Pulse Speed						ON	OFF					
	i uise opeeu	30	ms L0) / 50	ms H							OFF	ON
		150	ms LC	/ 150	ms H							ON	ON

★ Manufacture setting.

Note: 1. Default setting

- 2. Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.
- 3. Remove the front cover and the dip-switch in on the CPU board. (Please refer to "SW1" setting.)

Appendix

V7E/LX7-B0B4(Pulse/ICT104U/MDB/R\$232 A0)

DIP SWITCHES SETTING : 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4	
7	Credit-Pulse Normal High	ON				
	Credit-Pulse Normal Low	OFF				
	Pulse Mode		ON	OFF		
	ICT104U Interface		OFF	ON		
	MDB Interface		ON	ON		
	RS232 A0 Mode		OFF	OFF		
	Reserved				ON	
	reserved				OFF	

DIP SWITCHES SETTING: 2(ICT104U)

	FUNCTION	SW1	SW2	SW3	SW4
	Reserved	ON			
7	Reserved	OFF			
	Pulse Mode		ON	OFF	
r	ICT104U Interface		OFF	ON	
	MDB Interface		ON	ON	
	RS232 A0 Mode		OFF	OFF	
	Reserved		ON		
7	Reserved		OFF		

DIP SWITCHES SETTING: 2(MDB) Currency Assign Data

	FUNCTION	SW1	SW2	SW3	SW4
*	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
	Pulse Mode		ON	OFF	
	ICT104U Interface		OFF	ON	
*	MDB Interface		ON	ON	
	RS232 A0 Mode		OFF	OFF	
	Reserved				ON
*	Neserved		OFF		

Interface Bill value	Interface Pulse		RS232 A0	MDB	
BV1	BOB 10	BOB 10	BOB 10	BOB 10	
BV2	BOB 20	BOB 20	BOB 20	BOB 20	
BV3	BOB 50	BOB 50	BOB 50	BOB 50	
BV4	BOB 100	BOB 100	BOB 100	BOB 100	

DIP SWITCHES SETTING: 2(RS232 A0)

	FUNCTION	SW1	SW2	SW3	SW4
*	Reserved -				
	Pulse Mode		ON	OFF	
	ICT104U Interface		OFF	ON	
	MDB Interface		ON	ON	
*	RS232 A0 Mode		OFF	OFF	
	Reserved				ON
*					
′ I					

[★] Manufacture setting

Note: (1) Default setting.

BillType Data Code Denomination BOB 10 BOB 20 BOB 50 BOB 100 4 5 Reserved 6 Reserved Reserved 8 Reserved

Reserved

9

RS232 A0 INFORMATION

- (2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.
- (3) Remove the front cover and the dip-switch in on the CPU board.

(Please refer to "SW1" setting.)

V. 2.0 Part Number: SWP5BO42000-R

[★] Manufacture setting