

# XBA mini-TWD4

## XBA mini Option Switch Settings: 1(Pulse/MDB/JPSTD/ICT104V/ICT104U)

Supported bill TWD 100, 200, 500, 1000 4bills.

XBA mini dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject TWD 100	ON											
★ Accept TWD 100	OFF											
★ Reject TWD 200		ON										
★ Accept TWD 200		OFF										
★ Reject TWD 500			ON									
★ Accept TWD 500			OFF									
★ Reject TWD 1000				ON								
★ Accept TWD 1000				OFF								
Reserved					ON							
★ Reserved					OFF							
★ Disable Bill Reject 4 Times BA Stop By 30 Sec						ON						
★ Enable Bill Reject 4 Times BA Stop By 30 Sec						OFF						
★ Stack Banknote when Power-up							ON					
★ Reject Banknote when Power-up							OFF					
★ MDB special mode								ON				
★ Normal mode								OFF				
★ Inhibit Active High									ON			
★ Inhibit Active Low									OFF			
★ Reserved									ON			
★ Reserved									OFF			
★ Interface Timing Conversion		50ms LO / 50ms HI								OFF	OFF	
		60ms LO / 300ms HI								ON	OFF	
		30ms LO / 50ms HI								OFF	ON	
		150ms LO / 150ms HI								ON	ON	

★ Manufacture setting

Note : (1) After setting dip switch of the credit pulses,you should reset the bill acceptor again.  
(2) Calibration card is needed.

# XBA mini-TWD4(Pulse/MDB/JPSTD/ICT104V/ICT104U)

## Interface Settings: 2(Pulse)

INTERFACE	SW1	SW2	SW3	SW4
★ Credit-Pulse Normal HIGH	ON			
Credit-Pulse Normal LOW	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
★ 1 pulse / TWD100			OFF	OFF
5 pulses / TWD100			OFF	ON
10 pulses / TWD100			ON	OFF
25 pulses / TWD100			ON	ON

★ Manufacture setting

## Interface Settings: 2(ICT104U)

INTERFACE	SW1	SW2	SW3	SW4
★ Reserved	ON			
Reserved	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
★ ICT104U Mode			ON	OFF
★ ICT104V Mode			ON	ON

★ Manufacture setting

## Interface Settings: 2(MDB)

FUNCTION	SW1	SW2	SW3	SW4
★ Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2	ON			
Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
★ MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting

## Currency Assign Data

Interface Bill value	JPSTD	ICT104U	ICT104V	Pulse	MDB
BV1	100	100	100	100	100
BV2		200	200	200	200
BV3		500	500	500	500
BV4		1000	1000	1000	1000

## Interface Settings: 2(ICT104V)

INTERFACE	SW1	SW2	SW3	SW4
★ Connect with coin changer	ON			
Connect with ICT JPSTD converter board	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
MDB Mode			OFF	OFF
JPSTD Mode			OFF	ON
★ ICT104U Mode			ON	OFF
★ ICT104V Mode			ON	ON

★ Manufacture setting

## Interface Settings: 2(JPSTD)

FUNCTION	SW1	SW2	SW3	SW4
★ Normal Mode	ON			
ALONA NT851 Mode(NO Error Code)	OFF			
★ Pulse Mode		ON		
★ Other Mode		OFF		
★ MDB Mode			OFF	OFF
★ JPSTD Mode			OFF	ON
ICT104U Mode			ON	OFF
ICT104V Mode			ON	ON

★ Manufacture setting