V7E+/LX7-BGN2

V7E+/LX7 Option Switch Settings: 1(Pulse/ICT104U/M.D.B) Supported bill BGN 5, 10 2bills.

V7E dip-switch settings and functions:

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
	Reject BGN 5	ON											
*	Accept BGN 5	OFF											
	Reject BGN 10		ON										
*	Accept BGN 10		OFF										
	Reserved			ON									
*	Reserved			OFF									
	Reserved				ON								
*	Reserved				OFF								
	Reserved					ON							
*	Reserved					OFF							
	Reserved						ON						
*	Reserved						OFF						
	Pulse Mode	Other Mode											
	Harness Disable	BA stops working when fishing ON											
*	Harness Enable	Normal OFF											
	Inhibit Active High								ON				
*	Inhibit Active Low								OFF				
*	1 pulse / BGN 1						OFF	OFF					
	2 pulses / BGN 1	C						ON	OFF				
	4 pulses / BGN 1									OFF	ON		
	20 pulses / BGN 1									ON	ON		
*		50ms LO / 50ms HI						•	OFF	OFF			
,.	Dulas Casad	60ms LO / 300ms HI				ON	OFF						
	Pulse Speed	30ms LO / 50ms HI							OFF	ON			
	150ms LO / 150ms HI							ON	ON				

- ★ Manufacture setting
- Note: (1) Default setting.
 - (2) Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.
 - (3) Remove the front cover and the dip-switch in on the CPU board.

_Appendix

V7E+/LX7-BGN2(Pulse/ICT104U/M.D.B)

DIP SWITCHES SETTING: 2(Pulse)

	FUNCTION		SW2	SW3	SW4	
*	Pulse Normal High	ON				
	Pulse Normal Low	OFF				
	ICT104U Mode		OFF	ON		
*	Pulse Mode		ON	OFF		
	M.D.B Mode		ON	ON		
	Reserved		OFF	OFF		
	Reserved					
*						

DIP SWITCHES SETTING: 2(ICT104U) Currency Assign Data

	FUNCTION	SW1	SW2	SW3	SW4
*	Reserved	ON			
	Reserved	OFF			
*	ICT104U Mode		OFF	ON	
	Pulse Mode		ON	OFF	
	M.D.B Mode		ON	ON	
	Reserved		OFF	OFF	
	Reserved				ON
*	i veserved		OFF		

Interface Bill value	Pulse	MDB	ICT104U		
BV1	BGN 5	BGN 5	BGN 5		
BV2	BGN 10	BGN 10	BGN 10		

DIP SWITCHES SETTING: 2(M.D.B)

	FUNCTION	SW1	SW2	SW3	SW4
*	Scaling Factor (SF) = 100 Decimal Point Position (DPP) = 2				
	Scaling Factor (SF) = 1 Decimal Point Position (DPP) = 0				
	ICT104U Mode		OFF	ON	
*	Pulse Mode		ON	OFF	
	M.D.B Mode		ON	ON	
	Reserved		OFF	OFF	
*	Reserved				ON

- ★ Manufacture setting
- ♦ Use 2nd and 3rd dip of the internal dip-switch to change different interface protocol.