



# EUR2

## P70/P5 DIP SWITCHES SETTING : 1(M.D.B)

Supported bill Euro 5(02), 10(04) 2bills.

| FUNCTION   | SW1 | SW2 | SW3 | SW4 | SW5 | SW6 | SW7 | SW8 | SW9 | SW10 |
|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|
| ★ 1 Pulse / Euro 5                                       | OFF | OFF | OFF |     |     |     |     |     |     |      |
| 2 Pulse / Euro 5   | OFF | OFF | ON  |     |     |     |     |     |     |      |
| 3 Pulse / Euro 5   | OFF | ON  | OFF |     |     |     |     |     |     |      |
| 4 Pulse / Euro 5   | OFF | ON  | ON  |     |     |     |     |     |     |      |
| 5 Pulse / Euro 5   | ON  | OFF | OFF |     |     |     |     |     |     |      |
| 10 Pulse / Euro 5  | ON  | OFF | ON  |     |     |     |     |     |     |      |
| 20 Pulse / Euro 5  | ON  | ON  | OFF |     |     |     |     |     |     |      |
| 100 Pulse / Euro 5                                       | ON  | ON  | ON  |     |     |     |     |     |     |      |
| Fast output Pulse <small>Lo= 50ms<br/>Hi=100ms</small>   |     |     |     | ON  |     |     |     |     |     |      |
| ★ Slow output Pulse <small>Lo= 50ms<br/>Hi=300ms</small> |     |     |     | OFF |     |     |     |     |     |      |
| Inhibit level Active Low                                 |     |     |     |     | ON  |     |     |     |     |      |
| ★ Inhibit level Active High                              |     |     |     |     | OFF |     |     |     |     |      |
| ★ Accept Euro 5  |     |     |     |     |     | ON  |     |     |     |      |
| Reject Euro 5  |     |     |     |     |     | OFF |     |     |     |      |
| ★ Accept Euro 10   |     |     |     |     |     |     | ON  |     |     |      |
| Reject Euro 10   |     |     |     |     |     |     | OFF |     |     |      |
| HOLD   |     |     |     |     |     |     |     | ON  |     |      |
|  |     |     |     |     |     |     |     | OFF |     |      |
|  |     |     |     |     |     |     |     |     | ON  |      |
|  |     |     |     |     |     |     |     |     | OFF |      |
|  |     |     |     |     |     |     |     |     |     | ON   |
|  |     |     |     |     |     |     |     |     |     | OFF  |

★ Manufacture setting

Note: (1)Please reset the bill acceptor after set the dip switch.

(2)Dip switches 1 to 5 are only used for pulse protocol.

## DIP SWITCHES SETTING : 2

| FUNCTION                              | SW1 | SW2 | SW3 | SW4 |
|---------------------------------------|-----|-----|-----|-----|
| ★ Pulse Normal High                   | ON  |     |     |     |
| Pulse Normal Low                      | OFF |     |     |     |
| ★ Pulse Protocol                      |     | ON  |     |     |
| M.D.B Protocol                        |     | OFF |     |     |
| ★ Normal (M.D.B used)                 |     |     | ON  |     |
| Credit divided by 10 (M.D.B used)     |     |     | OFF |     |
| Ignore Sensor Problem (Note 1)        |     |     |     | ON  |
| ★ Acknowledge Sensor Problem (Note 2) |     |     |     | OFF |

★ Manufacture setting

Note : (1) Sensor 6 problem occurred ==>> BA will be still in working order.

(The face LED will be flashing in short green about 2 seconds everytime you restart BA.)

(2) BA will stop to work when it acknowledges Sensor 6 problem occurred.

(The face LED will be flashing in red.)

