



**ZAR5**

**P70/P5 DIP SWITCHES SETTING : 1(Pulse/ICT)**

**Supported bill R 10, 20, 50, 100, 200 5bills.**

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10		
★	1 Pulse / R 10	OFF	OFF	OFF									
	2 Pulse / R 10	OFF	OFF	ON									
	3 Pulse / R 10	OFF	ON	OFF									
	4 Pulse / R 10	OFF	ON	ON									
	5 Pulse / R 10	ON	OFF	OFF									
	10 Pulse / R 10	ON	OFF	ON									
	20 Pulse / R 10	ON	ON	OFF									
	100 Pulse / R 10	ON	ON	ON									
	Fast output Pulse <small>Lo= 50ms Hi=100ms</small>				ON								
★	Slow output Pulse <small>Lo= 50ms Hi=300ms</small>				OFF								
	Inhibit level Active Low				ON								
★	Inhibit level Active High				OFF								
★	Accept R 10											ON	
	Reject R 10					OFF							
★	Accept R 20												ON
	Reject R 20							OFF					
★	Accept R 50												ON
	Reject R 50								OFF				
★	Accept R 100												
	Reject R 100									OFF			
★	Accept R 200												
	Reject R 200										OFF		

★ Manufacture setting

Note: (1) Please reset the bill acceptor after set the dip switch.

(2) Dip switches 1 to 5 are only used for pulse protocol.

**DIP SWITCHES SETTING : 2**

	FUNCTION	SW1	SW2	SW3	SW4
★	Pulse Normal High	ON			
	Pulse Normal Low	OFF			
★	Pulse Protocol		ON		
	ICT Protocol		OFF		
	Reserved			ON	
★				OFF	
	Manufacture Default				ON
★	System Default				OFF

★ Manufacture setting

