BRV-AUD5

BRV Option Switch Settings: 1(ICT-BC/MDB/JPSTD Dummy/MDB Dummy)

Supported bill AUD 5, 10, 20, 50, 100   5bills.

BRV dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
Reject AUD 5	ON											
★ Accept AUD 5	OFF											
Reject AUD 10		ON										
★ Accept AUD 10		OFF										
Reject AUD 20			ON									
★ Accept AUD 20			OFF									
Reject AUD 50				ON								
★ Accept AUD 50				OFF								
Reject AUD 100					ON							
★ Accept AUD 100					OFF							
★ Normal						OFF	OFF					
Load Banknote to Recycle						ON	OFF					
Load Banknote to Stacker						OFF	ON					
Unload Banknote to Stacker						ON	ON					
Reserved								ON				
★ Reserved								OFF				

MDB Mode	MDB Dummy Mode	SW1	SW2	SW3	SW4	JPSTD Dummy Mode		SW1	SW2	SW3	SW4
Reserved	Reserved	ON				★ 255 Bank Note Limitation Per Transaction		ON	ON	ON	
★ Reserved	Reserved	OFF				1 Bank Note Limitation Per Transaction		OFF	OFF	OFF	
Reserved	Reserved		ON			2 Bank Note Limitation Per Transaction		ON	OFF	OFF	
★ Reserved	Reserved		OFF			3 Bank Note Limitation Per Transaction		OFF	ON	OFF	
Reserved	Reserved			ON		4 Bank Note Limitation Per Transaction		ON	ON	OFF	
★ Reserved	Reserved			OFF		5 Bank Note Limitation Per Transaction		OFF	OFF	ON	
						6 Bank Note Limitation Per Transaction		ON	OFF	ON	
						7 Bank Note Limitation Per Transaction		OFF	ON	ON	
Virtual MDB (Note.5) Recycler Function	No Refund After the Deal				ON	No Refund After the Deal					ON
★ Standard MDB Recycler Function	★ Refund After the Deal				OFF	★ Refund After the Deal					OFF

★ Manufacture setting

Note：(1) After setting dip switch of the credit pulses,you should reset the bill acceptor again.
(2) Please reset the bill acceptor after set the dip switch.
(3) Calibration card is needed.
(4) Recycled Banknote represents virtual MDB coin type.
(5) Virtual Coin Changer：Scaling Factor = 100, Decimal Point Position = 2.

BRV-AUD5(ICT-BC/MDB/JPSTD Dummy/MDB Dummy)

Interface Settings: 2(ICT-BC)

INTERFACE	SW5	SW6	SW7	SW8
★ Reserved	ON			
Reserved	OFF			
★ Connect with MDB Connector		ON		
Connect with RS232 Connector		OFF		
MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
★ ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(JPSTD Dummy)

INTERFACE	SW5	SW6	SW7	SW8
Escrow (JPSTD Dummy Mode)	ON			
★ No Escrow (JPSTD Dummy Mode)	OFF			
Reserved		ON		
★ Reserved		OFF		
MDB Mode			OFF	OFF
★ JPSTD Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB)

INTERFACE	SW5	SW6	SW7	SW8
★ Scaling Factor (SF)= 100 / Decimal Point Position (DPP)= 2	ON			
Scaling Factor (SF) = 1 / Decimal Point Position (DPP)= 0	OFF			
Reserved		ON		
★ Reserved		OFF		
★ MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
MDB Dummy Mode			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Interface Settings: 2(MDB Dummy)

INTERFACE	SW5	SW6	SW7	SW8
★ Reserved	ON			
Reserved	OFF			
Reserved		ON		
★ Reserved		OFF		
MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
★ MDB Dummy Mode (Note.5)			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

Currency Assign Data

Interface / Bill value	JPSTD Dummy	ICT-BC	MDB Dummy	Recycler banknote inventory
BV1	AUD 5	AUD 5	AUD 5	AUD 5	35 pcs
BV2	AUD 10	AUD 10	AUD 10	AUD 10	35 pcs
BV3	AUD 20	AUD 20	AUD 20	AUD 20	35 pcs
BV4	AUD 50	AUD 50	AUD 50	AUD 50	30 pcs
BV5	AUD 100	AUD 100	AUD 100	AUD 100	30 pcs