

# BRV-ILS4

## BRV Option Switch Settings: 1(ICT-BC/MDB/JPSTD Dummy)

Supported bill ILS 20, 50, 100, 200 4bills.

BRV dip-switch settings and functions:

FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4
★ Reject ILS 20	ON											
★ Accept ILS 20	OFF											
★ Reject ILS 50		ON										
★ Accept ILS 50		OFF										
★ Reject ILS 100			ON									
★ Accept ILS 100			OFF									
★ Reject ILS 200				ON								
★ Accept ILS 200				OFF								
Reserved					ON							
★ Reserved					OFF							
★ Normal						OFF	OFF					
Load Banknote to Recycle						ON	OFF					
Load Banknote to Stacker						OFF	ON					
Unload Banknote to Stacker						ON	ON					
Reserved								ON				
★ Reserved								OFF				
MDB Mode	SW1	SW2	SW3	SW4	JPSTD Dummy Mode							
Reserved	ON				★ 255 Bank Note Limitation Per Transaction	ON	ON	ON				
★ Reserved	OFF				1 Bank Note Limitation Per Transaction	OFF	OFF	OFF				
Reserved		ON			2 Bank Note Limitation Per Transaction	ON	OFF	OFF				
★ Reserved		OFF			3 Bank Note Limitation Per Transaction	OFF	ON	OFF				
Reserved			ON		4 Bank Note Limitation Per Transaction	ON	ON	OFF				
★ Reserved			OFF		5 Bank Note Limitation Per Transaction	OFF	OFF	ON				
Reserved				ON	6 Bank Note Limitation Per Transaction	ON	OFF	ON				
★ Reserved				OFF	7 Bank Note Limitation Per Transaction	OFF	ON	ON				
Virtual MDB Recycler Function (Note.4)				ON	No Refund After the Deal							ON
★ Standard MDB Recycler Function				OFF	★ Refund After the Deal							OFF

★ Manufacture setting

Note : (1) After setting dip switch of the credit pulses, you should reset the bill acceptor again.

(2) Please reset the bill acceptor after set the dip switch.

(3) Calibration card is needed.

(4) Recycled Banknote represents virtual MDB coin type.

# BRV-ILS4(ICT-BC/MDB/JPSTD Dummy)

## Interface Settings: 2(ICT-BC)

INTERFACE	SW5	SW6	SW7	SW8
Reserved	ON			
★ Reserved	OFF			
Connect with MDB Connector		ON		
★ Connect with RS232 Connector		OFF		
MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
Reserved			ON	OFF
★ ICT-BC Mode			ON	ON

★ Manufacture setting

## Interface Settings: 2(JPSTD Dummy)

INTERFACE	SW5	SW6	SW7	SW8
Escrow (JPSTD Dummy Mode)	ON			
★ No Escrow (JPSTD Dummy Mode)	OFF			
Reserved		ON		
★ Reserved		OFF		
MDB Mode			OFF	OFF
★ JPSTD Dummy Mode			OFF	ON
Reserved			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

## Interface Settings: 2(MDB)

INTERFACE	SW5	SW6	SW7	SW8
★ Scaling Factor (SF)= 100 Decimal Point Position (DPP)= 2	ON			
Scaling Factor (SF)= 1 Decimal Point Position (DPP)= 0	OFF			
Reserved		ON		
★ Reserved		OFF		
★ MDB Mode			OFF	OFF
JPSTD Dummy Mode			OFF	ON
Reserved			ON	OFF
ICT-BC Mode			ON	ON

★ Manufacture setting

# Currency Assign Data

Interface Bill value	JPSTD Dummy	ICT-BC	MDB	Recycler banknote inventory	
BV1	ILS 20	ILS 20	ILS 20	ILS 20	35 pcs
BV2	ILS 50	ILS 50	ILS 50	ILS 50	35 pcs
BV3	ILS 100	ILS 100	ILS 100	ILS 100	35 pcs
BV4	ILS 200	ILS 200	ILS 200	ILS 200	30 pcs