L77F/PL77-CHF4

<u>L77F&PL77 DIP SWITCHES SETTING : 1(Pulse/ICT104U/ccTalk)</u>

Supported bill CHF 10, 20, 50, 100 4bills.

	FUNCTION	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW9	SW10
*	1 Pulse / CHF 10	OFF	OFF	OFF							
	2 Pulse / CHF 10		OFF	ON							
	3 Pulse / CHF 10		ON	OFF							
	4 Pulse / CHF 10		ON	ON							
	5 Pulse / CHF 10		OFF	OFF							
	10 Pulse / CHF 10		OFF	ON							
	20 Pulse / CHF 10	ON	ON	OFF							
	100 Pulse / CHF 10	ON	ON	ON							
	Fast output Pulse Lo= 50ms Hi=100ms				ON						
*	Slow output Pulse Lo= 50ms Hi=300ms				OFF						
	Inhibit level Active Low					ON					
*	Inhibit level Active High					OFF					
*	Accept CHF 10						ON				
	Reject CHF 10						OFF				
*	Accept CHF 20							ON			
	Reject CHF 20							OFF			
*	Accept CHF 50								ON		
	Reject CHF 50								OFF		
*	Accept CHF 100									ON	
	Reject CHF 100									OFF	
*	Reserve							ON			
	Reserve							OFF			

★ Manufacture setting

Note:(1) Please reset the bill acceptor after any changes on Dip switch.

- (2) Dip Switch 1 to 5 are only for Pulse mode.
- (3) Turn this dip to with restart the bill acceptor will restore ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

PL77/L77F-CHF4(Pulse/ICT104U/ccTalk)

DIP SWITCHES SETTING: 2(Pulse)

	FUNCTION	SW1	SW2	SW3	SW4
*	Credit-Pulse Normal High	ON			
	Credit-Pulse Normal Low				
*	Pulse Mode		ON	OFF	
	ccTalk Interface		OFF	OFF	
	ICT104U Mode		ON	ON	
	Reserved		OFF	ON	
	Reserved				ON
*					

[★] Manufacture setting

DIP SWITCHES SETTING: 2(ccTalk)

FUNCTION	SW1	SW2	SW3	SW4
8-bit checksum	ON			
CRC 16-bit checksum	OFF			
Pulse Mode		ON	OFF	
ccTalk Interface		OFF	OFF	
ICT104U Mode		ON	ON	
ccTalk Parameters Restore Switch Please see "Note" for detail		OFF	ON	
Encryption Mode				ON
Decrypt Mode				OFF
	8-bit checksum CRC 16-bit checksum Pulse Mode ccTalk Interface ICT104U Mode ccTalk Parameters Restore Switch Please see "Note" for detail Encryption Mode	8-bit checksum ON CRC 16-bit checksum OFF Pulse Mode ccTalk Interface ICT104U Mode ccTalk Parameters Restore Switch Please see "Note" for detail Encryption Mode	8-bit checksum ON CRC 16-bit checksum OFF Pulse Mode ON ccTalk Interface OFF ICT104U Mode ON ccTalk Parameters Restore Switch Please see "Note" for detail Encryption Mode	8-bit checksum ON CRC 16-bit checksum OFF Pulse Mode ON OFF CCTalk Interface OFF OFF ICT104U Mode ON ON ccTalk Parameters Restore Switch Please see "Note" for detail OFF ON Encryption Mode OFF ON

[★] Manufacture setting

Note: Put this switch to on and reset power will restore the ccTalk address to its default value of 40 and the encryption key to its default value of 123456.

DIP SWITCHES SETTING: 2(ICT104U)

	FUNCTION	SW1	SW2	SW3	SW4
*	Reserved				
	Pulse Mode		ON	OFF	
*	ccTalk Interface		OFF	OFF	
	ICT104U Mode		ON	ON	
	Reserved		OFF	ON	
*	Reserved				ON
					OFF

Currency Assign Data

Interface Bill value	Puls	se	ICT10)4U	ccTalk		
BV1	CHF	10	CHF	10	CHF	10	
BV2	CHF	20	CHF	20	뜐	20	
BV3	CHF	50	CHF	50	CHF	50	
BV4	CHF	100	CHF	100	CHF	100	

[★] Manufacture setting

^{© 2016} International Currency Technologies Corporation V. 2.0 Part Number : SWY6CH42000-R